

PowerVac®



Service and Parts Manual

Model Numbers:

Single Vac Units

P3

P5

P7

Twin Vac Units

P6

P10

P14



FOR USE BY MIDMARK TRAINED TECHNICIANS ONLY

Table Of Contents

General Information

GENERAL INFORMATION

Symbols	iii
Ordering Parts	iii
Serial Number Location	iii
Specifications	iv
Model Identification / Compliance Charts:	v
Warranty Information	vi

Section A

TROUBLESHOOTING

Vacuum System	A-2
Electrical System Operation	
<i>Power to System</i>	A-3
Wall Switch On	A-4
Bottom Float contact Closed	A-5
Middle Float Contact Closed	A-6
Top Float Contact Closed	A-7
Liquid Evacuation Pump (Accessory)	A-11

Section B

TESTING & REPAIR

Belt	B-2
Check Valve	B-6
Vacuum Relief Valve	B-9
Exhaust	B-12
Float	B-15
Low Voltage	B-18
Door Limit Switch & Circuit Breaker (On/Off Switch)	B-21
Contactor	B-26
Fuse	B-28
Relay	B-31
Transformer	B-34

Section B - cont.

TESTING & REPAIR - continued

Fan	B-37
Gauge	B-41
Motor	B-43
Capacitor	B-44
Pump	B-50
Liquid Evacuation Pump (Accessory)	B-53
Separator Tank	B-58

Section C

ACCESS PROCEDURES

Front Cover	C-2
Top Cover	C-3
Electrical Cover	C-4
Back Cover (Previous Tank) ...	C-5
Back Cover (Large Tank)	C-6

Section D

WIRING DIAGRAMS

PowerVac®	D-2*
Liquid Evacuation Pump (Accessory)	D-4

Section E

EXPLODED VIEWS / PARTS LISTS

PowerVac® Single Models (P3, P5, P7)	E-2*
PowerVac® Twin Models (P6, P10, P14)	E-3*
Liquid Evacuation Pump (Accessory)	E-4*

* Indicates multiple pages due to model / serial number break(s)

Symbols



Caution

Indicates a potentially hazardous situation which could result in injury if not avoided.



Equipment Alert

Indicates a potentially hazardous situation which could result in equipment damage if not avoided.

Note

Amplifies a procedure, practice, or condition.



Indicates that the component the check mark appears beside should be tested before replacing it. In Section A, test the components in the order indicated. (ex. **1st** ✓ then, **2nd** ✓)

Refer to Section B for component testing procedures.

These symbols are used throughout this manual to represent the operational status of table functions and components.



Indicates the function / component is working properly. No action required.



Indicates the function / component is working, but a problem exists.



Indicates the function / component is not working at all.

Ordering Parts

The following information is required when ordering parts:

- Serial number & model number
- Part number for desired part.

[Refer to Exploded Views / Parts Lists section]


Non-warranty parts orders may be faxed to Midmark using the Fax Order Form in the back of this manual.

For warranty parts orders, call Midmark's Technical Service Department with the required information.

Hours: 8:00 am until 5:00 pm EST [Monday - Friday]

Phone: 1-(800)-Midmark

Model / Serial Number Location



Serial / Model Number

AA1580001

General Information

Weights, Dimensions, Electrical Specifications

Classifications: Class 1, Type B Applied Part

	Model P3	Model P5	Model P7	Model P6	Model P10	Model P14	Evacuation Control Box (Optional)
Max Users	3-5	5-7	7-10	6-10	10-14	14-20	N/A
Vac Unit H x W x D	26" x 19.5" x 18.5"	26" x 19.5" x 18.5"	26" x 19.5" x 18.5"	26" x 39" x 18.5"	26" x 39" x 18.5"	26" x 39" x 18.5"	N/A
Separator H x W x D	32" x 22" x 22"	32" x 22" x 22"	32" x 22" x 22"	32" x 22" x 22"	32" x 22" x 22"	32" x 22" x 22"	5" x 5.5" x 6"
Actual Weight (lbs)	Vac Unit - 355 Separator - 47	Vac Unit - 355 Separator - 47	Vac Unit - 355 Separator - 47	Vac Units - 710 Separators - 94	Vac Units - 710 Separators - 94	Vac Units - 710 Separators - 94	2
Total HP	2	2	2	4	4	4	N/A
Voltage	208 / 230	208 / 230	208 / 230	208 / 230	208 / 230	208 / 230	115 VAC
Amps	11.4	11.4	11.4	22.8	22.8	22.8	3
Hertz	60	60	60	60	60	60	60
Recommended Breaker Size (Amps) (Min. 20 Amp ea.)	30	30	30	2 x 30	2 x 30	2 x 30	15
Inlet Connection Size (in.)	1 1/2"	1 1/2"	1 1/2"	2"	2"	2"	N/A
Fuses	1/8 A, 250V Type T	1/8 A, 250V Type T	1/8 A, 250V Type T	1/8 A, 250V Type T	1/8 A, 250V Type T	1/8 A, 250V Type T	1/4A, 250V, Type T 3A, 250V, Type T
Drain Connection Size (in.)	1 1/2"	1 1/2"	1 1/2"	1 1/2"	1 1/2"	1 1/2"	N/A

Model Identification / Compliance Chart - PowerVac®

Model	Description	Serial Number Prefix	Complies To:		Electrical Supply Requirements:		
			UL 60601--1	CAN/CSA 22.2, #601.1-M90	VAC	Amps	Cycles (Hz)
P3	PowerVac® Dry Vacuum System - Single - 3 User	V	X	X	208-230	11.4	60
P5	PowerVac® Dry Vacuum System - Single - 5 User	V	X	X	208-230	11.4	60
P7	PowerVac® Dry Vacuum System - Single - 7 User	V	X	X	208-230	11.4	60
P6	PowerVac® Dry Vacuum System - Twin - 6 User	V	X	X	208-230	22.8	60
P10	PowerVac® Dry Vacuum System -Twin - 10 User	V	X	X	208-230	22.8	60
P14	PowerVac® Dry Vacuum System - Twin - 14 User	V	X	X	208-230	22.8	60

Warranty Information

LIMITED WARRANTY

SCOPE OF WARRANTY

Midmark Corporation (“Midmark”) warrants to the original purchaser its new PowerVac® products and components (except for components not warranted under “Exclusions”) manufactured by Midmark to be free from defects in material and workmanship under normal use and service. Midmark’s obligation under this warranty is limited to the repair or replacement, at Midmark’s option, of the parts or the products the defects of which are reported to Midmark within the applicable warranty period and which, upon examination by Midmark, prove to be defective.

APPLICABLE WARRANTY PERIOD

The applicable warranty period, measured from the date of installation for the original user, shall be five (5) years or 10,000 usage hours (whichever comes first) for all warranted products and components and ten (10) years or 20,000 usage hours (whichever comes first) for the pump only.

EXCLUSIONS

This warranty does not cover and Midmark shall not be liable for the following: (1) repairs and replacements because of misuse, abuse, negligence, alteration, accident, freight damage, or tampering; (2) products which are not installed, used, and properly cleaned as required in the Midmark “Installation” manual and or PowerVac® Care Guide for this applicable product; (3) products considered to be of a consumable nature; (4) accessories or parts not manufactured by Midmark; (5) charges by anyone for adjustments, repairs, replacement parts, installation, or other work performed upon or in connection with such products which is not expressly authorized in writing in advance by Midmark.

EXCLUSIVE REMEDY

Midmark’s only obligation under this warranty is the repair or replacement of defective parts. Midmark shall not be liable for any direct, special, indirect, incidental, exemplary, or consequential damages or delay, including, but not limited to, damages for loss of profits or loss of use.


NO AUTHORIZATION

No person or firm is authorized to create for Midmark any other obligation or liability in connection with the products.

THIS WARRANTY IS MIDMARK’S ONLY WARRANTY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. MIDMARK MAKES NO IMPLIED WARRANTIES OF ANY KIND INCLUDING ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT OF DEFECTIVE PARTS.

Section A

Troubleshooting



<u>Function / System</u>	<u>Page</u>
Vacuum System	A-2
Electrical System Operation	
Power to System	A-3
Wall Switch On	A-4
Bottom Float Contact Closes	A-5
Middle Float Contact Closes	A-6
Top Float Contact Closes	A-7
Liquid Evacuation Pump.....	A-11

Troubleshooting

Vacuum System Operation

Operatory waste (air, solids and liquids) is pulled into the separator through the inlet hose by the rotary claw pump in the vacuum base unit.

Air is separated from liquids and solids. Air then flows into the pump and out through the exhaust hose.

Fresh air is pumped in through the Vacuum Relief Valve to the pump and out through the exhaust. (When ports are opened in the operatories the VRV closes to compensate.)


The check valve connected below the drain port allows the unit to drain liquids and solids upon removal of vacuum from the chamber when the pump / motor shuts off.

The fan(s), hour meter and vacuum pump start to run when power is supplied by the wall switch. The fan(s) and hour meter then begin to cycle with the vacuum pump / motor. The float switches control the pump motor by a 24 vac relay via motor contactor.

The upper and lower reed switch floats interact as a latching circuit with the internal relay to release upon drain below the bottom float.

Refer To:	Page
Low or No Suction	A-9

Earlier Version Shown





Electrical System (Power to System Wall Switch Open All Float Switches Open)

- Power (230 VAC) is on supplying Line Voltage to the Vacuum Pump Electrical System.
- 230 V is applied to the 230 V / 24 V Transformer energizing it.
- 24 V is applied from one side of Transformer, to the Terminal Block.
- From the Terminal Block, 24 V is applied to Terminal 6 of CR1 Relay, thru CR1 normally closed contacts (6 & 2) to one side of the coil on Contactor "C", also to J1 & J2 Plug (pin 1), and thru the Timer to one side of the Wall On / Off Light.
- 24 V is also applied thru the closed Door Limit Switch, Circuit Breaker & Timer to one side of the Wall On/Off Switch.

Refer To:	Page
Motor will not Run	A-10
Motor Cutting Out	A-11

NOTE:
Some units have dual fans that are wired in parallel.



NOTE:
Manual reset button on earlier versions, automatic reset on current versions.

Water Low, All Float Switches Open

Models: All
Serial Numbers:

Power to System

Troubleshooting

Electrical System - continued (Wall Switch On, Power to System, All Float Switches Open)


- Remote Wall Switch is turned on, the On / Off Light comes on.
- 24 V is applied to the other side of the coil of Contactor "C", energizing the coil and closing its contacts.
- The Fan(s), Hour Meter, and Vacuum Pump run.

Electrical System - continued (Wall Switch OFF, Power to System, All Float Switches Open, Timer ON)


- Remote Wall Switch is turned off, the Timer turns on and starts to measure two hours.
- The Timer will run the Vacuum for one minute every two hours while the Remote Wall Switch is turned off by completing the 24 V circuit to the Contactor "C" coil.

NOTE:
Some units have dual fans that are wired in parallel.


VACUUM PUMP ELECTRICAL SYSTEM



NOTE:
Manual reset button on earlier versions, automatic reset on current versions.



Water Low, All Float Switches Open




Circuit Breaker & Door Limit Switch Closed

Electrical System - continued (Water Rises, Bottom Float Switch Closes, Middle and Top Switches Remain Open.)

- Contactor "C" contacts remain closed.
- The Fan(s), Hour Meter, and Vacuum Pump continue to run.


SEPARATOR FLOAT SWITCH ASSEMBLY Earlier Version Shown

Earlier Version Has Three Reed Switch Floats. The Middle Float in Current Version is Not Used and No Longer Installed




NOTE:
Some units have dual fans that are wired in parallel.

VACUUM PUMP ELECTRICAL SYSTEM



Bottom Float Switch Closed, Middle and Top Remain Open.



NOTE:
Manual reset button on earlier versions, automatic reset on current versions.

Models: All
Serial Numbers:

Bottom Float Switch Closed


Troubleshooting

Electrical System - continued (Water Reaches Middle Float, Middle and Bottom Float Switches are Closed, Top Switch Remains Open.)

- Contactor "C" contacts remain closed.
- The Fans, Hour Meter, and Vacuum Pump continue to run.


SEPARATOR FLOAT SWITCH ASSEMBLY Earlier Version Shown

Earlier Version Has Three Reed Switch Floats. The Middle Float in Current Version is Not Used and No Longer Installed




AA1608021

Middle and Bottom Float Switches are Closed, Top Remains Open.



VACUUM PUMP ELECTRICAL SYSTEM



NOTE:
Some units have dual fans that are wired in parallel.

NOTE:
Manual reset button on earlier versions, automatic reset on current versions.


AA24781

Electrical System - continued (Water Reaches Top Float, All Float Switches are Closed.)

- The Top Float Switch sends 24v to the coil of CR1 Float Switch Relay changing the contacts position.
- Power is removed from the coil of Contactor "C", opening its contacts.
- The Fan(s), Hour Meter, and Vacuum Pump stop running.
- CR1 Float Switch Relay remains energized through its own normally closed tips (6&4) and the bottom float switch (pin 3) of J1& J2
- The Collection tank starts to Drain, Pump remains off until Bottom Float Switch opens interrupting 24v to the CR1 Float Switch Relay coil.
- CR1 Float Switch Relay returns to its normal state energizing Contactor "C", the Vacuum Pump, Fan(s) Motors, and Hour Meter restart.

SEPARATOR FLOAT SWITCH ASSEMBLY Earlier Version Shown


Earlier Version Has Three Reed Switch Floats. The Middle Float in Current Version is Not Used and No Longer Installed



All Float Switches are Closed.

NOTE:
Some units have dual fans that are wired in parallel.

VACUUM PUMP ELECTRICAL SYSTEM



Models:
Serial Numbers:

All

Top Float
Switch Closed


Troubleshooting

Vacuum System

Problem: Operatory has low or no suction.

Refer To:	Page
Motor will not Run	A-9
Belt	B-2
Check Valve	B-6
Vacuum Relief Valve	B-9
Exhaust	B-12

Earlier Version Shown



1st ✓
Will the motor start?
If motor runs go to 2nd check.
If not Refer to Section A - Motor will not run.

2nd ✓
Check Belt Tension.
Refer to: Section B - Belt.
(Earlier Version ONLY)

3rd ✓
Check Hoses and Bulkhead Fittings.
Check for leaks, kinks and loose connections in the hoses, bulkhead fittings and separator lid gasket.

6th ✓
Check Exhaust.
Remove exhaust line to see if suction increases.
Unclog or replace exhaust line if suction increased when checking.
Refer to: Section B - Exhaust

5th ✓
Check Vacuum Relief Valve.
Refer to: Section B - Vacuum Relief Valve.


4th ✓
Check Drain Line for Suction.
Refer to: Section B - Check Valve.

Earlier Version Shown

Vacuum System

Problem: Motor will not run.

Refer To:	Page
Door Limit Switch.....	B-20
Float.....	B-15
Pump	B-49
Low Voltage	B-18
Motor	B-42
Contactor	B-25
Fuse	B-27
Relay	B-30



Earlier Version Shown

Check Float.

Refer to: Section B - Float

6th ✓

Is Pump locked up?

Refer to: Section B - Pump

1st ✓

Reset Thermal Overload.

Refer to: Section B - Motor

2nd ✓

Check Door Limit Switch.

Refer to: Section B - Door Limit Switch

3rd ✓

Check Fuse.

Refer to: Section B - Fuse

5th ✓

Check Relay.

Refer to: Section B - Relay

7th ✓

Check Contactor.

Refer to: Section B - Contactor

8th ✓

Check Low Voltage.


Refer to: Section B - Low Voltage

4th ✓

Check Motor.

Refer to: Section B - Motor

9th ✓



Earlier Version Shown

Models:
Serial Numbers:

All

Motor Not Running

Troubleshooting

Vacuum System

Problem: Motor cutting out or running at a reduced speed.

Refer To:

Page

Contactor	B-25
Pump	B-44
Exhaust	B-12
Motor	B-42

1st ✓

Check Equipment Room Temperature.
Temperature should be - 40° to 104° Fahrenheit
- 4 to 37 Celsius

4th ✓

Check Exhaust line and valve.
Refer to: Section B - Exhaust

2nd ✓


Check Contactor Voltage.
Refer to: Section B - Contactor

5th ✓

Check Motor.
Refer to: Section B - Motor

3rd ✓

Is Pump locked up?
Refer to: Section B - Pump



Earlier Version Shown

Electrical System for Accessory - Liquid Evacuation Pump

The Liquid Evacuation Pump is an optional accessory for the PowerVac®.

- 115 VAC is applied to the 115V / 24V Transformer energizing it.
- 24 VAC is applied from one side of the Transformer to the J3 plug.
- When the water level reaches the *Bottom* float switch, K3 relay contact closes.
- When the water level reaches the *Middle* float switch, K2 & K4 relay contact close. Power is supplied to J8 and J9 terminals, energizing the Liquid Evacuation Pump.

NOTE:


The Liquid Evacuation Pump will continue to run until the water level drops below the *Bottom* float switch, opening K3 & K4 relay contacts.

If the *Top* float closes, K1 relay contacts close, and its LED is on, a problem is occurring with the system. Check for a restriction in the lines, pump not functioning, or PC board problem.

Refer To:	Page
Evacuation Pump Will Not Run	A-12
Pump Runs But Will Not Pump	A-13
Pump tripping Thermal Overload	A-14

Optional Liquid Evac Pump Must use a Three Float Assembly

Liquid Evacuation Pump Electrical System shown when the Bottom & Middle Float Switches are Closed and Pump is running. (Liquid Evac Pump is Optional)



AA158503i

Models:	All
Serial Numbers:	

**Liquid Evac Pump
Electrical**

Troubleshooting

Evacuation Pump System

Problem: Evacuation Pump will not run.

Check Low Voltage to PC Board

Refer to: Section B - Liquid Evacuation Pump

2nd ✓

Check PC Board

Refer to: Section B - Liquid Evacuation Pump

5th ✓

Check Supply Voltage to PC Board

Refer to: Section B - Liquid Evacuation Pump

1st ✓

Check Float Assembly

Refer to: Section B - Float Assembly

3rd ✓

Check Thermal Motor Protector

Refer to: Section B - Liquid Evacuation Pump

4th ✓

Check Pump Motor

Refer to: Section B - Liquid Evacuation Pump

6th ✓

Refer To:

Page

Liquid Evacuation Pump

Check Supply VoltageB-53-B-56


Check Low Voltage.....B-53-B56

Check Float Assembly B-15

Check Thermal Motor Protector...B-53-B-56

Check PC Board.....B-53-B-56

Check Pump Motor.....B-53-B-56



Earlier Version Shown

Earlier Version Shown

Evacuation Pump Will Not Run


Models:
Serial Numbers:

All

Evacuation Pump System

Problem: Evacuation Pump runs but does not remove liquid from Separator.

Refer To: Page
Liquid Evacuation Pump.....B-53-B-56



4th ✓
Check Supply Voltage to Pump
Supply voltage is low.
Refer to: Section B - Liquid Evacuation Pump


2nd ✓
Check for Obstructions in Outlet of Separator / Lines.
Refer to: Section B - Liquid Evacuation Pump

5th ✓
Check Pump Location
Pump should be positioned as close as possible below the separator.

1st ✓
Check Suction Line Into Pump
Check for leaks.
Avoid "looping" suction pipe as it could trap air.
Suction line should not be more than 6 ft. in length.

6th ✓
Check Discharge Line from Pump
Do not run a discharge head of greater than 35 ft. (15 Psi).

3rd ✓
Check Evac. Pump Impeller for Obstructions or Damage.
Refer to: Section B - Liquid Evacuation Pump



Earlier Version Shown

Models: All
Serial Numbers:

Evacuation Pump Runs but Will Not Pump

Troubleshooting

Evacuation Pump System

Problem: Evacuation Pump Motor keeps tripping on Thermal Overload.

Check Ambient Temperature at Motor

Temperature should not exceed 104° F (40° C) around pump.

6th ✓

Refer To:

Page

Liquid Evacuation Pump B-52

Check Supply Voltage to Pump

Supply voltage is low.
Refer to: Section B - Liquid Evacuation Pump

1st ✓

Check for Obstructions in Discharge Line from Pump

Refer to: Section B - Liquid Evacuation Pump

2nd ✓

Check Pump Location

Pump should be positioned as close as possible below the separator.
Suction line should not be more than 6 ft. in length.

5th ✓

Motor Thermal Protector Weak

Replace motor pump.

7th ✓

Check Discharge Line from Pump


Do not run a discharge head of greater than 35 ft. (15 Psi).

3rd ✓

Check Evac. Pump Impeller for Obstructions or Damage.

Refer to: Section B - Liquid Evacuation Pump


4th ✓



Earlier Version Shown

Section B

Testing & Repair



<u>Components:</u>	<u>Page</u>
Belt	B-2
Check Valve	B-6
Vacuum Relief Valve	B-9
Exhaust	B-12
Float	B-16
Low Voltage	B-18
Door Limit Switch & Circuit Breaker (On/Off Switch)	B-21
Contactor	B-26
Fuse	B-28
Relay	B-31
Transformer	B-34
Fan	B-37
Gauge	B-41
Motor	B-43
Pump	B-50
Liquid Evacuation Pump (Accessory) ..	B-53
Separator Tank (Rinse).....	B-58

Testing & Repair

Belt


Location & Function

The Belt runs on a motor pulley system operating the pump. Belt should never have nicks, cracks or any visible damage, this will affect performance.

Earlier versions of the PowerVac® the belt will need adjusting from time to time. Newer versions of the PowerVac® have an auto tensioner.

Refer to:	Page
Belt Adjustment (Tension)	B-3
Belt Replacement (Earlier Version)	B-4
Belt Replacement (New Version)	B-5

WARNING
Motors installed after 12/08 are thermally protected with automatic reset. Unit may start without warning.




Earlier Version Shown

AA162300i

Belt

Checking and Adjusting Belt Tension (Earlier Versions Only)



Check belt tension using belt tension checker...

- A. Remove front cover. Refer to: Section C Front Cover.
- B. Position o-ring on large end of tension checker to 12" (use "Inches of Span Length" increments on checker).
- C. Slide o-ring on small shaft to 0 pounds.
- D. Align straight edge with belt.
- E. Apply force on the plunger until o-ring on large shaft is even with straight edge.
- F. Remove the tension checker and read the deflection force the small o-ring was moved to.

Verify deflection reading is 7 lbs.



WARNING

Motors installed after 12/08 are thermally protected with automatic reset. Unit may start without warning.

If adjustment is needed...


- A. Loosen Motor Mount Bolt.
- B. Move adjustment nut clockwise to tighten belt.
- C. Move adjustment nut counter clockwise to loosen belt.
- D. Use belt tension checker to recheck deflection reading.
- E. Tighten motor mount bolt.
- F. Replace front cover.

If no adjustment is needed...

- A. Tighten motor mount bolt.
- B. Replace front cover.

Refer to:

	Page
Belt Location and Function	B-2
Belt Replacement (Earlier Version)	B-4
Belt Replacement (New Version)	B-5
Front Cover	C-2



AA168200i

Models:
Serial Numbers:

P3
0611P3P0000 to 0801P3P0611
V245092 to V317654

P5
0611P5P0000 to 0801P5P0240
V245092 to V317641

P7
0611P7P0000 to 0712P7P0104
V245092 to V317634

Belt


Testing & Repair

Belt

WARNING
 Motors installed after 12/08 are thermally protected with automatic reset. Unit may start without warning.

Replacement
 (Earlier Versions Only)


Removal
Step 1: Disconnect power at on/off switch and main power supply box.



Refer to:	Page
Belt Location and Function	B-2
Belt Adjustment (Earlier Version)	B-3
Belt Replacement (New Version)	B-5
Front Cover	C-2

Caution
 The On/Off switch controls only the secondary circuit power. The main power source must be turned off to remove all power in the control box.

Removal
Step 2: Remove front cover.
 Refer to: Section C - Front Cover



Removal
Step 3: Loosen motor mount bolt and adjustment bolt.

Removal
Step 4: Remove belt.

Installation
Step 5: Replace belt.

Installation
Step 6: Tighten adjustment bolt and motor mount bolt.

Installation
Step 7: Set belt tension.
 Refer to: Section B - Belt Adjustment

Installation
Step 8: Replace front cover.

Installation
Step 9: Connect power.

AA162700i

Models:	P3	P5	P7
Serial Numbers:	0611P3P0000 to 0801P3P0611 V245092 to V317654	0611P5P0000 to 0801P5P0240 V245092 to V317641	0611P7P0000 to 0712P7P0104 V245092 to V317634

Belt


Replacement
(Newer Versions Only)



WARNING
Motors installed after 12/08 are thermally protected with automatic reset. Unit may start without warning.


Refer to:	Page
Belt Location and Function	B-2
Belt Adjustment (Earlier Version)	B-3
Belt Replacement (Earlier Version)	B-4
Front Cover	C-2

Step 1: Disconnect power at on/off switch and main power supply box.




Step 2: Remove front cover.
Refer to: Section C Front Cover

Step 3: Slightly push tension arm up toward the pulley and remove belt with other hand.



Step 4: Slightly push tension arm up toward the pulley and install new belt with other hand.



Step 5: Replace front cover.

Models:	P3	P5	P7	All
Serial Numbers:	0802P3P0612 thru Present	0801P5P0241 thru Present	0712P7P0105 thru Present	V785000 thru Present

Belt

Testing & Repair

Check Valve



Location and Function

The Check Valve located in the drain allows the separator to drain upon removal of vacuum pressure. When the pump is not running, the valve opens, allowing liquids to drain. If the pump is running the valve closes to keep air in the drain from back flushing into the system.

Each vacuum pump in a multiple pump installation requires a check valve to be installed into the intake line.


This prevents loss of suction pressure when one pump in the system is turned off. If no check valve is present, flow will be allowed through the "off" pump, creating a loss suction of the rest of the system.

Refer to:	Page
Check Valve Test	B-7
Check Valve Replacement	B-8



Located at bottom drain on all units

Earlier Version Shown




Multiple Units have two additional check valves, located in the Tee Assembly

Note: When installing check valve in horizontal position, confirm the hinge for the flapper is on top of the valve.

Check Valve

Testing

Refer to: **Page**
Check Valve Location and Function B-6
Check Valve Replacement B-8



Step 2: Turn vacuum off and ensure that water drains from separator.

Step 1: Vacuum 1-2 gallons of fresh water into system through operator lines.


Note: If water does not drain out, remove lid and see if valve is clogged. (If so flush and clean tank, if not replace valve.) If water drains out, continue with next test on step 3.

Step 3: Turn power off.

Step 4: Allow unit to drain completely.

Step 5: Pull drain hose out of drain.

Earlier Version Shown



Step 6: Turn power on and place hand over end of drain hose.
Note: If you feel suction check valve is stuck, replace check valve. If no suction is felt then check valve is good.

Models: All
Serial Numbers:

Check Valve

Testing & Repair

Check Valve

Replacement


All Units

Refer to:	Page
Check Valve Location and Function	B-6
Check Valve Test	B-7



Earlier Version Shown
AA162900i

Removal Step 1: Turn power off.




Installation Step 6: Turn power on and place hand over end of check valve.

Note: Verify you do NOT feel any suction.

- Twin Units**
- Removal Step 1:** Turn power off.
 - Removal Step 2:** Remove drain hose from check valve.
 - Removal Step 3:** Unscrew check valve.

Twin Unit Tee Assembly Check Valves



Installation Step 4: Install check valve.

Installation Step 5: Install drain hose to check valve.

Vacuum Relief Valve

Location and Function


The Vacuum Relief Valve regulates the vacuum pressure in the PowerVac®.

The Vacuum Relief Valve has a 1" NPT male fitting on one side and 1" NPT female fitting on the other side.

The valve is adjustable up to 18"Hg. Recommended range for the system vacuum is from 10" to 18"Hg. The valve is preset at the factory for 12" Hg.

The Vacuum Relief Valve is located on top of the separator tank in the "T" Fitting on Single Models and in the center of the mounted "T" assembly on the Twin Models.

Refer to:	Page
VRV Adjustment	B-10
VRV Replacement	B-11



Models:	All
Serial Numbers:	

Vacuum Relief Valve

Testing & Repair

Vacuum Relief Valve

Adjustment

Refer to:

VRV Location and Function B-9


VRV Replacement B-11

Page


Step 2: Remove the filter and valve by unscrewing from tee-fitting.

Step 1: Turn power off.

Single Unit Location




Earlier Version Shown



Step 3: Adjust the center mounted screw inside the valve.

Note: Use 1/4 inch nutdriver and phillips screwdriver.
Each full clockwise turn increases the vacuum level by approximately 2 inch Hg.

Twin Unit Location



Step 4: Install filter and valve.

Note: Recommended Range is 10" Hg - 18 Hg.
Vacuum is preset at 12" Hg.
If reading is low check for leaks or open operatory lines.

Vacuum Relief Valve


Replacement

Refer to:	Page
VRV Location and Function	B-9
VRV Adjustment	B-10

Removal


Step 1: Turn power off.

Single Unit Location



Earlier Version Shown

Twin Unit Location



Removal

Step 2: Unscrew valve from tee-fitting.
Unscrew valve from filter.

Installation

Step 3: Screw filter onto valve.
Screw valve assembly into tee-fitting.

Installation

Step 4: Turn power on.

Installation

Step 5: Perform Adjustment.
Refer to: Section B - VRV Adjustment

Models:
Serial Numbers:

All

Vacuum Relief Valve


Testing & Repair

Exhaust Valve

Location and Function

The exhaust check valve provides protection for the pump. It prevents moisture from entering the pump from the exhaust line.

Refer to:	Page
Exhaust Valve Check	B-13
Exhaust Valve Replacement	B-14



Earlier Version Shown

Exhaust Valve

Check

Refer to:	Page
Exhaust Valve Location and Function ...	B-12
Exhaust Valve Replacement	B-14

Step 1: Turn power off.

Barbed Fitting

Exhaust Valve


Step 2: Remove exhaust hose from barbed fitting.
Remove barbed fitting.

Step 3: Remove exhaust valve from nipple.

Nipple

Step 4: Shake valve and listen for movement of flap.

Note: If you are able to hear the valve flap moving, it is good. If valve is stuck and not moving, remove valve and clean. If valve will not work, replace the exhaust valve. Refer to: Section B Replacement



Earlier Version Shown

AA163400i

Models:
Serial Numbers:

All

Exhaust Valve

Testing & Repair

Exhaust Valve

Replacement


Removal

Step 1: Turn power off.

Refer to:

Page

Exhaust Valve Location and Function .. B-12



Installation

Step 5: Screw barbed fitting into exhaust valve.
Connect exhaust hose to barbed fitting.

Nipple →

Removal


Step 3: Remove exhaust valve from nipple.

Installation

Step 4: Screw new exhaust valve onto nipple.

Installation

Step 6: Turn power on.



Earlier Version Shown

AA163400i

Float Assembly

Location and Function

The Float Assembly contains three Float (Reed) Switches mounted on a bracket at different intervals.

The Reed Switch has contacts that remain open until the liquid in the separator rises, causing the float to rise until the magnet contacts the Reed Switch.

When the magnet contacts the Reed Switch, the open contacts inside the reed close.



When the top float switch closes, the fan, hour meter and vacuum pump stop running until the bottom float opens and the cycle starts again.

The upper and lower floats interact as a latching circuit with the internal relay to release upon drain below the bottom float. The magnet in the float is to activate the reed switch within the stem.

If the PowerVac® has a Liquid Evacuation Pump (Accessory) installed, it begins running when the middle float switch closes, avoiding the vacuum pump shut-off that would occur if the liquid level closed the top switch.

Earlier Versions had Three Reed Switch Floats. The Middle Float was for the Liquid Evac Pump Option. If You Have a Liquid Evac Pump Connected to the PowerVac you Must Replace Float With a Three Reed Switch Float Assembly. If There is No Evac Pump Connected to the PowerVac, You can Replace the Float With a Two Reed Switch Float Assembly.

Refer to:	Page
Check Float	B-16
Replace Float	B-17



Models:	All
Serial Numbers:	

Float Assembly

Testing & Repair

Float Assembly

Check

Earlier Versions had Three Reed Switch Floats. The Middle Float was for the Liquid Evac Pump Option. If You Have a Liquid Evac Pump Connected to the PowerVac you Must Replace Float With a Three Reed Switch Float Assembly. If There is No Evac Pump Connected to the PowerVac, You can Replace the Float With a Two Reed Switch Float Assembly.

Refer to:	Page
Float Location and Function	B-15
Replace Float	B-17
Rinse Separator Tank	B-58
Relay Test	B-32


To check float switches...

Note: *If pump is not running, unplug float from base unit. If pump doesn't start running, test relay (Section B) if pump starts running, continue with float checks...*

- A) Turn power off and plug float into base unit.
- B) Remove gasket on separator lid.
- C) Lift lid/float assembly out of tank and lay across top of tank.
- D) Turn power on.
- E) Move floats to down position.
- F) Raise bottom float to reed switch, then raise top float to reed switch. Motor should stop after top switch is raised.
- G) Move top float down first, then lay bottom float down.
Motor should not start until bottom float is down.

Note: Floats should move freely, if float does not work properly, replace the float assembly.

Note: *If no water in separator, but still runs when unplugged from vacuum base unit, float maybe stuck.*



Current Version Shown


AA2336

Float Assembly

Replacement

Earlier Versions had Three Reed Switch Floats. The Middle Float was for the Liquid Evac Pump Option. If You Have a Liquid Evac Pump Connected to the PowerVac you Must Replace Float With a Three Reed Switch Float Assembly. If There is No Evac Pump Connected to the PowerVac, You can Replace the Float With a Two Reed Switch Float Assembly.

Refer to:	Page
Float Location and Function	B-15
Check Float	B-16




Float Cord Fitting

Removal

Step 3: Lift separator lid.
Hold onto float underneath lid.
Loosen float cord fitting on top of separator.
Float will come down into your hand.

Removal

Step 1: Turn power off.
Unplug float cord.




Installation

Step 6: Plug in float cord to vacuum base unit.
Turn power on.

Installation

Step 4: Insert new float assembly up through separator lid.
Tighten float cord fitting on top of separator.




Removal

Step 2: Pull gasket down off separator lid.

Installation

Step 5: Set lid on separator.
Install gasket.



Earlier Version
Shown

AA163700i

Models:
Serial Numbers:

All

Float Assembly

Testing & Repair


Master Control Panel and Low Voltage

Location and Function

Wiring for Remote ON/OFF Switch, Master Control Panel

Low voltage (24VAC) wiring provides power for a remote ON/OFF switch and indicator light (optional).

Refer to:	Page
Master Control Panel Test	B-19
Low Voltage Test	B-20



AA163400i *Earlier Version Shown*

Master Control Panel


Test




Caution
When testing components with power on use care to prevent electrical shock.

Refer to:	Page
Location and Function	B-18
Low Voltage Test	B-20

Step 1: Disconnect power at on/off switch and main power supply box.




Step 2: Bypass the remote switch to verify it is not defective. Disconnect the Red and Blue wires from the remote switch. Connect the Blue and Red wires together.



Step 3: Connect power to the PowerVac®
Turn the On/Off switch On.

Note: If the fan, hour meter and pump start running then replace the remote switch.



Earlier Version Shown

AA1635001

Models:
Serial Numbers:

All

Low Voltage

Testing & Repair

Low Voltage

Test

 **Caution**
When testing components with power on use care to prevent electrical shock.

Refer to:	Page
Location and Function	B-18
Master Control Panel Testing	B-19
Access Procedures	C-1

Step 1: Turn power off.


Step 2: Remove electrical cover.
Refer to: Section C Access Procedures

Step 3: Set meter to \tilde{V} .

Step 4: Turn power on.



Step 5: Place probes on red low voltage wire on contactor and yellow wire coming from transformer.
Note: Verify voltage is 24 VAC.



Door Limit Switch & PowerVac® Circuit Breaker (ON/OFF Switch)

Location & Function

With facility power (230 VAC) supplied to the system...

The transformer continuously supplies 24 VAC to the normally-open door limit switch.

With the front access cover in place...

The plastic bumper on the top right side of the access cover, trips the door limit switch causing it to close.


When the limit switch is closed, 24 VAC flows thru the switch to the PowerVac® circuit breaker (ON / OFF Switch). With the circuit breaker switch ON, current is supplied to the remote wall switch (if applicable).

Note: If the facility does not have a remote wall switch, the PowerVac® circuit breaker serves as the ON/OFF switch for the system.

When the front access cover is removed...

The door limit switch opens and stops current flow to the PowerVac® circuit breaker. This is a safety feature that prevents the system from operating with the cover removed.

<u>Refer to:</u>	<u>Page</u>
Door Limit Switch Testing	B-22
Circuit Breaker (On/Off) Testing	B-23
Door Limit Switch Replacement	B-24
Circuit Breaker Replacement (On/Off)	B-25



Earlier Version Shown

Models:	All
Serial Numbers:	

**Door Limit Switch
On/Off Switch**

Testing & Repair

Door Limit Switch

Testing

Step 1: Turn power off.

Step 2: Remove front cover.
Refer to: Section C Front Cover.

Refer to:	Page
Door Limit / Circuit Breaker Function ..	B-21
Circuit Breaker (On/Off) Testing	B-23
Door Limit Switch Replacement	B-24
Circuit Breaker Replacement (On/Off)	B-25
Section C Front Cover	C-2




Caution

During this step, the motor belt and pulley may spin with front cover off. Stay clear and keep everything out of the vacuum base!

Step 3: Turn power on and depress activation button with a screwdriver.

Note: If motor starts up, quickly take pressure off switch. Plastic bumper may be obstructed or damaged. Check plastic bumper on door for damage. If it is damaged, switch it with plastic bumper on opposite side of door until a replacement can be ordered. If motor doesn't start, continue with step 4.

Step 4: Turn power off.




Caution

When testing components with power on use care to prevent electrical shock.

Mounting Screw

Step 5: Remove mounting screw for door limit switch. Disconnect electrical leads.



Caution

Door limit switch is a safety device. If switch is not working, do not bypass. Warranty will be void if switch is bypassed. If both tests fail, it must be replaced!

Limit Switch Test

Step 6: Test continuity. Set meter to Ω . Place meter probes on **COM** and **NO** terminals.

Note: Check switch 'tripped' and 'untripped'.

Step 7: Install front cover.

With switch 'untripped'...

Meter Reading Status Required Action

OL		Limit switch - OK
less than 5 Ω		Replace switch

With switch 'tripped'...

Meter Reading Status Required Action

OL		Replace switch
less than 5 Ω		Limit switch - OK

Door Limit Switch &
Circuit Breaker

Models:
Serial Numbers:


All

Circuit Breaker (ON/OFF Switch)

Testing

Step 1: Turn power off.

Step 2: Remove front cover.
Refer to: Section C Front Cover.



Caution

When testing components with power on use care to prevent electrical shock.

Refer to:


Page

Door Limit / Circuit Breaker Function	B-19
Door Limit Switch Testing	B-20
Door Limit Switch Replacement	B-22
Circuit Breaker Replacement (On/Off) ..	B-23
Front Cover	C-2

Circuit Breaker Test

Step 3: Test continuity. Set meter to Ω .
Disconnect leads from switch terminals.
Place meter probes on **COM** and **NO** terminals.

Note: Check switch 'tripped' and 'untripped'.



Step 4: Connect switch leads.
Install front cover.

Meter Reading	Status	Required Action
OL		Circuit Breaker is Good
less than 5 Ω		Replace Circuit Breaker

With switch 'tripped'...

Meter Reading	Status	Required Action
OL		Replace Circuit Breaker
less than 5 Ω		Circuit Breaker is Good

Models:
Serial Numbers:

All

Door Limit Switch &
Circuit Breaker

Testing & Repair

Door Limit Switch

Replacement




Caution

The On/Off switch controls only the secondary circuit power.
The main power source must be turned off to remove all power in the control box.
Vacuum system must not have power when front cover is off base unit.

Removal

Step 1: Disconnect power at on/off switch and main power supply box.



WARNING

Motors installed after 12/08 are thermally protected with automatic reset. Unit may start without warning.

Plunger

Mounting Screw



Removal


Step 3: Disconnect wires from limit switch.

Removal

Step 2: Remove front cover.
Refer to: Section C Front Cover

Installation

Step 6: Connect wiring to limit switch.



Mounting Screw

Removal

Step 4: Remove mounting screw and pull out limit switch and bracket.
Remove switch from bracket.

Installation

Step 5: Align limit switch with hole in side panel and plunger away from mounting screws.
Install mounting screw as shown.

Installation

Step 7: Install front cover.

Installation

Step 8: Turn power source on.

Refer to:

Page

Door Limit / Circuit Breaker Function .. B-21
Door Limit / Circuit Breaker Testing B-22
Circuit Breaker (On/Off) Testing B-23
Circuit Breaker Replacement (On/Off) B-25
Front Cover C-2

Circuit Breaker (ON/OFF Switch)

Replacement

Removal

Step 1: Disconnect power at on/off switch and main power supply box.

Removal

Step 2: Remove front cover.
Refer to: Section C Front Cover

Removal

Step 4: Push in on both side of breaker and push forward to pull out of panel.

Installation

Step 5: Push in on both sides of breaker.
Push breaker into panel and release sides to snap it in to place.

Installation

Step 6: Install front cover and restore power.

Removal

Step 3: Disconnect wires from back of breaker.

Refer to:

Page


Door Limit / Circuit Breaker Function B-19

Door Limit Switch Test B-20

Circuit Breaker (On/Off) Testing B-21

Door Limit Switch Replacement B-22

Front Cover C-2



AA165603

Models:
Serial Numbers:

All

Door Limit Switch &
Circuit Breaker


Testing & Repair

Contactor

Location and Function

When the PowerVac® is turned on either by the remote wall switch or vacuum unit on/off switch, the Contactor is energized. It sends current to the fan, hour meter and pump, turning them on.


Refer to:	Page
Contactor Testing	B-27



Earlier Version Shown

Contactor


Test

Caution
 When testing components with power on use care to prevent electrical shock.

Refer to: [Contactor Location and Function](#) B-26
[Electrical Cover](#) C-4


Step 1: Turn power off.

Step 2: Remove electrical cover.
 Refer to Section C: Electrical Cover.




Step 3: Turn power on.

Step 4: Check high voltage on contactor.
 • Set meter to V.
 • Place meter probes on front, left side red and black wires.
 Note: Verify reading is line volts.





Step 6: Insert screwdriver to start manually.
 Note: if system starts, replace contactor.

Step 5: Check voltage across contactor.
 • Set meter to V.
 • Place meter probes on top red wire and bottom black wire.
 Note: Verify reading is 24 volts.



Step 7: Install electrical cover.

Note: Line Voltage should be 208 - 230 VAC with circuit loaded (equipment running)

Meter Reading	Status	Required Action
Line Volts (Left side check)		Contactors OK
24 Volts (Top and Bottom check)		Contactors OK

Models: All
Serial Numbers:

Contactors

Testing & Repair


Fuse

Location and Function

The fuse limits the electrical current from the transformer to the contactor. It interrupts the electrical currents in the case of an overload.

Only replace fuse with 1/8 amp, 250 volt, Slo Blo, fuse.

Refer to:	Page
Fuse Testing	B-29
Fuse Replacement	B-30



Earlier Version Shown


Fuse

Testing


Refer to:	Page
Fuse Location and Function	B-28
Fuse Replacement	B-30
Electrical cover	C-4

Step 1: Turn power off.

Step 2: Remove electrical cover.
Refer to Section C: Electrical Cover.



AA1643011



Step 3: Remove terminal leads.
Test continuity. Set meter to Ω .
Place meter probes on both fuse terminals.

Step 4: Visually check fuse to see if it is burnt or broken.

Step 5: Install electrical cover.

Meter Reading	Status	Required Action
OL - off line Burnt or Broken		Replace Fuse
Continuity checks ok Visually looks ok		Fuse is Good

Models: | **All**
Serial Numbers: |

Fuse

Testing & Repair


Fuse

Replacement

Removal
Step 1: Turn power off.

Removal
Step 2: Remove electrical cover.
Refer to: Section C - Electrical Cover

Removal
Step 3: Pull fuse out.



Refer to:	Page
Fuse Location and Function	B-28
Fuse Testing	B-29
Electrical cover	C-4

Installation
Step 4: Insert new fuse and perform continuity test.
Refer to: Section B Fuse Test

Installation
Step 5: Install electrical cover.


Relay

Location and Function

Power is disconnected from the Contactor when the relay is energized by the top float switch closing (water level reaching top float switch).

The PowerVac® electrical system can be checked by pressing the test button on the side. If the unit shuts down, the rest of the electrical system is functioning properly.

Refer to:	Page
Relay Testing	B-32
Relay Replacement	B-33



Earlier Version Shown

Models:
Serial Numbers:

All

Relay

Testing & Repair

Relay

Test

Note: If the motor is **not shutting off** when the top collection tank float is actuated, check relay by pressing the **Test Button**.
If the motor is **not running**, **By-Pass Relay** to check operation.

Refer to:	Page
Relay Location and Function	B-30
Relay Replacement	B-32
Electrical cover	C-4


Caution
When testing components with power on use care to prevent electrical shock.

Relay Test Button. (Motor not off with top float actuated)

Step 1: Turn power off.
Step 2: Remove electrical cover. Refer to Section C: Electrical Cover.
Step 3: Verify all wire connections are secure to relay.
Step 4: Turn power on.
Step 5: Push in test button on side of relay, if unit shuts down, relay is bad.


Note: If the unit does not shut down when top float is activated, but shuts off properly when the relay test button is pressed, the coil in the relay is likely defective (barring any other wiring issues). The light on the relay is only an indicator that there is power to the coil.

24V from transformer



By-Pass Relay Test

Step 1: Turn power off.
Step 2: Disconnect blue wire from Relay(2) and connect wire to left side of Relay(6) which has a direct feed from the transformer.
Step 3: Turn power on.



Test Results	Status	Required Action
Unit Starts when Relay Is By-Passed		Replace Relay
With the Top Collection Tank Float Actuated, Unit Only Shuts OFF When Relay Test Button is Depressed		Replace Relay

Relay

Replacement

Removal


Step 1: Disconnect power at on/off switch and main power supply box.

Removal

Step 2: Remove electrical cover. Refer to Section C: Electrical Cover.

Removal

Step 3: Unplug relay from base.



AA164600i

Refer to:

	Page
Relay Location and Function	B-30
Relay Testing	B-31
Electrical cover	C-4

Installation

Step 5: Install electrical cover.

Installation

Step 4: Plug in new relay. Restore power. Push in test button to verify unit shuts down after turning power on.

Models:
Serial Numbers:

All

Relay


Testing & Repair

Transformer

Location and Function

The Transformer steps the 230 VAC supply down to 24 VAC. This is the voltage at the relay and terminal block.

Refer to:	Page
Transformer Testing	B-35
Transformer Replacement	B-36




Transformer

Testing

Step 1: Turn power off.

Step 2: Remove electrical cover.
Refer to Section C: Electrical Cover.



Caution


When testing components with power on use care to prevent electrical shock.

Refer to:

Transformer Location and Function B-34
Transformer Replacement B-36
Electrical cover C-4

Page

Step 3: Verify all wire connections are secure to transformer, relay and terminal block.



Step 4: Feel transformer to verify it is not hot.
If it is hot, allow it to cool off.

Note: Transformer has a internal non-resetting overload fuse. If transformer is hot to touch, allow to cool before testing. If it's hot check ambient operating temp and input / output voltage. Verify ambient room temperature doesn't exceed 104° Fahrenheit (37 Celsius).

Step 5: Turn power on.

Step 6: Check low voltage on transformer connections.

- Set meter to V.
- Place meter probe on yellow wire connection from transformer to terminal block.
- Place meter probe on blue wire connection from transformer to relay.

Note: Verify reading is 24 volts (-2 / +4).

Step 7: Install electrical cover.

Meter Reading

Status

Required Action

Exceeds 24 Volts -2 / +4		Replace Transformer
Within 24 Volts -2 / +4		Transformer is Good

Models:
Serial Numbers:

All

Transformer

B-35

Testing & Repair

Transformer

Replacement

Removal

Step 1: Disconnect power at on/off switch and main power supply box.

Removal


Step 2: Remove electrical cover.
Refer to Section C: Electrical Cover.

Removal

Step 3: Disconnect all transformer wiring.

Removal

Step 4: Unscrew transformer from electrical box.



Installation

Step 5: Screw new transformer into electrical box.

Installation

Step 6: Connected wiring.

Installation

Step 7: Install electrical cover.
Resotre power.

Refer to:

Transformer Location and Function B-33
Transformer Testing B-35
Electrical cover C-4

Page

Fans


Location and Function

Depending on the version of PowerVac® you have, single or dual fans are used to cool the base unit by circulating air whenever the pump is running. The ON/OFF function of the fans are controlled by the CR1 relay.

With the CR1 Relay OPEN (light OFF), 230 VAC is supplied to the fan(s) thru Contactor "C". When voltage is applied to the fan(s), the fan(s) is energized.+

With the CR1 Relay CLOSED (light ON) there is no current flow to the Contactor "C" or to the fan(s). The fan(s) do not run.

Fans in the earlier version of PowerVac® models are located on a mounting bracket above the pump. Dual fans on newer versions are located on the back cover and are wired in parallel with the same electrical box connections as the single fan unit.



Earlier Version



New Version

<u>Refer to:</u>	<u>Page</u>
Fan Testing	B-38
Fan Replacement (Earlier Version)	B-39
Fan Replacement (New Version)	B-40

Models:
Serial Numbers:

All

Fan

Testing & Repair


Fan

Testing (if fan is not running)

Step 1: Disconnect power at on/off switch and main power supply box.



Step 2: Newer Versions - Remove back cover.
Refer to Section C: Back Cover.

Step 3: Set meter to \checkmark .



Caution
When testing components with power on use care to prevent electrical shock.

Step 4: Unplug harness from fan. Turn power on at base unit and supply power box.
Note: Verify pump is running. If pump is not running, Check for 230 volts where fan(s) connect to contactor.



Fan Plug Connection

AA164700i

Step 5: Verify fan harness connection to contactor is tight and not loose.
Check voltage in fan harness.

Note: Verify reading is 230 volts.

Meter Reading	Required Action
230 Volts	Replace Fan
<230 Volts	Replace Harness

Refer to:	Page
Fan Location and Function	B-37
Fan Replacement (Earlier Version)	B-39
Fan Replacement (New Version)	B-40
Electrical Cover	C-4
Back Cover	C-5

Fan


Replacement (Earlier Versions Only)

Removal

Step 1: Disconnect power at on/off switch and main power supply box.

Removal

Step 3: Disconnect plug wires from fan.



Removal

Step 4: Unscrew fan mounting bracket from vac base unit.

Removal

Step 5:

- Unscrew fan guard from mounting bracket.
- Remove fan from back of mounting bracket.

Exhaust Valve Assembly

Removal

Step 2:

- Remove drain hose.
- Unscrew exhaust valve assembly.

Installation

Step 6:

- Screw fan guard through front of mounting bracket and into new fan.
- Screw mounting bracket into vac base unit.

Installation

Step 7:

- Connect plug wires to fan.
- Install exhaust valve assembly.

AA164800i

Refer to:

Page

Fan Location and Function	B-37
Fan Testing	B-38
Fan Replacement (New Version)	B-39
Electrical cover	C-4

Models:
Serial Numbers:

P3
0611P3P0000 to 0801P3P0611
V245092 to V784999

P5
0611P5P0000 to 0801P5P0240
V245092 to V784999

P7
0611P7P0000 to 0712P7P0104
V245092 to V784999

Fan

Testing & Repair

Fans


Replacement

Removal

Step 1: Disconnect power at on/off switch and main power supply box.

Removal

Step 2: Remove back cover.
Refer to: Section C Back Cover



Removal

Step 4: Unscrew fan units from inside of cover.

Installation

Step 5: Screw fan units onto inside of cover.

Removal

Step 3: Unscrew fan guards from outside of cover.

Installation

Step 6: Screw fan guards onto outside of cover.

Installation

Step 7: Replace back cover.
Restore power.

Refer to:

Page


Fan Location and Function	B-37
Fan Testing	B-38
Fan Replacement (Earlier Version)	B-39
Back Cover	C-5

Gauge

Location and Function

The Vacuum Gauge has a 1/4" NPT fitting and a range from 0 to -30 In./Hg. graduated in increments of 0.5 In./Hg. Recommended range for the system vacuum is 10"Hg to 18"Hg. The system is preset at the factory for 12"Hg.

Refer to:	Page
Gauge Replacement	B-42



Earlier Version Shown

Models:	All
Serial Numbers:	


Gauge

Testing & Repair

Gauge

Replacement


Removal
Step 1: Turn power off.



Refer to: Page
Gauge Location and Function B-41

Installation
Step 3: Apply teflon tape to threads on new gauge.

Removal
Step 2: Unscrew gauge from fitting.



Installation
Step 4: Screw new gauge into fitting.


Earlier Version Shown

Motor

Location & Function

The electric motor is located on an adjustable motor mount and is easily accessible. A thermal overload switch is located on the side of the motor (Red Button). The belt driven motor is a 2 HP single phase, 208-230 volt motor.

Earlier Version Shown



WARNING

Motors installed after 12/08 are thermally protected with automatic reset. Unit may start without warning.

Refer to:

Page

Motor Checks B-44

Belt B-2

Front Cover C-2

Earlier Versions

Motor Replacement (Removal) B-45

Motor Replacement (Installation) B-46


Motor Mount Adjustment B-47

Newer Versions

Motor Replacement (Removal) B-48

Motor Replacement (Installation) B-49

Earlier Version Shown



Models:
Serial Numbers:

All

Motor

Testing & Repair

Motor




Caution

The On/Off switch controls only the secondary circuit power. The main power source must be turned off to remove all power in the control box. Capacitors must be discharged before touching to remove.

Check

Step 1: Turn off power at on/off switch and power supply box.




Step 2: Remove front cover. Remove belt and verify motor pulley spins freely. If it doesn't, replace motor, bearing is out in motor. If it does, continue checks.

Refer to: Section C - Front Cover

Wire Connections

Step 3: Remove electrical cover off motor. Verify all wires are connected.




Earlier Version Shown Thermal Overload Button

Capacitor


Step 5: Replace Capacitor.

- Access start and run capacitor by removing top cover and capacitor covers off motor.
- Discharge capacitors by touching two screwdrivers to two contacts on a capacitor and to each other.

Refer to: Section C Top Cover



Discharge Capacitor



Reset Thermal Overload - Earlier Version Only

Step 4:



- Allow motor to cool.
- Press thermal overload button.
- Install front cover.
- Connect Power.

Note: Manual reset button on earlier versions only, current versions have automatic reset.

Step 6: Set meter to highest Ω reading.



WARNING
Motors installed after 12/08 are thermally protected with automatic reset. Unit may start without warning.



Step 7: Place meter probes on capacitor connectors.

Meter Reading	Status	Required Action
"O" or "Open" Reading		Replace Capacitor
Start Low and Increases		Capacitor - OK

Refer to:	Page
Motor Location and Function	B-42
Belt	B-2
Front Cover	C-2
Top Cover	C-3
<i>Earlier Versions</i>	
Motor Replacement (Removal)	B-44
Motor Replacement (Installation)	B-45
Motor Mount Adjustment	B-46
<i>Newer Versions</i>	
Motor Replacement (Removal)	B-47
Motor Replacement (Installation)	B-48

Motor (Removal)



Caution

The On/Off switch controls only the secondary circuit power. The main power source must be turned off to remove all power in the control box.

Refer to:


Page

Motor Location and Function	B-42
Motor Checks	B-43
Motor Replacement (Installation)	B-45
Belt	B-2
Front Cover	C-2

Replacement (Earlier Versions Only)

Removal

Step 1: Disconnect power at on/off switch and main power supply box



Removal

Step 5: Measure end of shaft to face of top pulley. Write dimension down.



Removal

Step 2: Remove front cover. Refer to: Section C - Front Cover

Removal

Step 6:

- Unscrew removal bolts from hub through holes.
- Screw bolts into threaded removal holes alternately to pull sheave off tapered hub.

Sheave

Removal Bolts
Removal Bolt Holes

Removal

Step 7: Disconnect motor wires from vac unit.

Removal

Step 3: Loosen motor mount bolt and adjustment bolt.

Motor Wire Connections

Removal

Step 4: Remove belt.

Adjustment Bolt

Removal

Step 8: Remove motor nuts and washers. Remove motor.

AA1658001

Models:
Serial Numbers:

P3
0611P3P0000 to 0801P3P0611
V245092 thru V784999

P5
0611P5P0000 to 0801P5P0240
V245092 thru V784999

P7
0611P7P0000 to 0712P7P0104
V245092 thru V784999

Motor


Testing & Repair

Motor (Install)

Replacement (Earlier Versions Only)
(Continued)

Installation

Step 9: Install new motor, nuts and washers onto motor mount.



Motor Wire Connections

Installation

Step 10: Connect motor wires from vac unit to motor.

Refer to:

Page

Motor Location and Function	B-42
Motor Checks	B-43
Motor Replacement (Removal)	B-44
Belt	B-2
Front Cover	C-2



Equipment Alert

For proper pulley alignment and function dimension measured should equal what you measured with the old pulley.

Installation

Step 11: Align key stock and install pulley and belt. Measure end of shaft to face to sheave.

Pulley
Motor Mount Bolt

Installation


Step 12: Tighten adjustment bolt and motor mount bolt.

Installation

Step 13: Check belt tension. Refer to: Section B - Belt Adjustment

Installation

Step 14: Replace front cover.



Bolts

Adjustment Bolt

AA165900i

Installation

Step 15: Restore power.


Models:	P3	P5	P7
Serial Numbers:	0611P3P0000 to 0801P3P0611 V245092 thru V784999	0611P5P0000 to 0801P5P0240 V245092 thru V784999	0611P7P0000 to 0712P7P0104 V245092 thru V784999

Refer to:	Page
Front Cover	C-2
Belt	B-2

Motor


Adjustment (Earlier Versions Only)

Step 1: Disconnect power at on/off switch and main power supply box.



Step 2: Remove front cover. Refer to: Section C - Front Cover

Step 3: Loosen motor mount bolt.



Step 5: Check belt tension. Refer to: Section B - Belt

Step 6: Tighten motor mount bolt.

Step 4: Move adjustment nut clockwise to tighten belt or counter clockwise to loosen belt.

Step 7: Replace front cover. Restore power.

AA168200i

Models:	P3	P5	P7
Serial Numbers:	0611P3P0000 to 0801P3P0611 V245092 to V784999	0611P5P0000 to 0801P5P0240 V245092 to V784999	0611P7P0000 to 0712P7P0104 V245092 to V784999

Motor


Testing & Repair

Motor

Replacement (New Versions Only)

Removal

Step 1: Disconnect power at on/off switch and main power supply box.



Removal

Step 3: Measure end of shaft to face of top pulley. Write dimension down.



Refer to:

Page


Motor Location and Function	B-42
Motor Checks	B-43
Motor Replacement (Removal)	B-48
Belt	B-2
Front Cover	C-2

Removal

Step 2: Remove front cover.
Refer to: Section C - Front Cover

Removal


Step 4: Slightly push tension arm up toward the pulley and remove belt with other hand.



Removal


Step 5: Remove pulley from motor.

- Unscrew removal bolts from hub through holes.
- Screw bolts into threaded removal holes alternately to pull sheave off tapered hub.



Removal

Step 6: Disconnect motor wires from vac unit.



Removal

Step 7: Remove motor from motor mount.


Motor (Install)

Replacement (New Versions Only)
(Continued)

Refer to:	Page
Motor Location and Function	B-42
Motor Checks	B-43
Motor Replacement (Removal)	B-47
Belt	B-2
Front Cover	C-2

Installation

Step 8: Install new motor, nuts and washers onto motor mount.



Installation

Step 9: Connect motor wires from vac unit to motor.




Equipment Alert

For proper pulley alignment and function dimension measured should equal what you measured with the old pulley

Installation

Step 10: Align key stock and install pulley and belt. Measure end of shaft to face to pulley.



Installation


Step 11: Slightly push tension arm up toward the pulley and install belt with other hand.

Installation

Step 12: Replace front cover. Refer to: Section C - Front Cover

Installation

Step 13: Connect power.



Models:
Serial Numbers:

P3
0802P3P0612 to Present

P5
0801P5P0241 to Present

P7
0712P7P0105 to Present

All
V785000 thru
Present

Motor


Testing & Repair

Pump


Location & Function

The "dry" vacuum pump requires no lubricant in the pumping chamber. The pump is a dual rotary claw type, belt driven by a 2 HP single phase, 208-230 volt motor.

Refer to:	Page
Pump Checks	B-51
Pump - Change Gear Lube	B-52




Earlier Version Shown



Earlier Version Shown

Refer to:	Page
Pump, Location and Function	B-50
Pump, Change Gear Lube	B-52
FrontCover	C-2

Step 1: Disconnect power at on/off switch and main power supply box.




Pump

Check

Step 2: Check pulley to see if locked up.

- Use belt to check pulley.
- Try to work pulley loose, turn with hand.


Note: If pulley does not move, continue with Steps 3, 4 and 5.



Drain Plug

Step 3: Check gear lubricant level.
Add if below 1/3 full. Use only Midmark gear lube P/N 064-0028-01.
Remove inlet hose to add gear lube.

Note: If you have added gear lube two times or more during the past year, call Dealer for service. If gear lube is not light yellow /clear opaque color, it will need to be changed. Refer to: Section B - Pump, Change Gear Lube.



To Drain Pump

Step 4: Check for water in pump.


- Remove drain bolt off pump & barb fitting at the bottom of the exhaust p-trap to release any water inside.
- When pump & p-trap are done draining replace drain bolt and barb fitting.

Note: Water may flood out, set funnel under bolt hole to move water from pump into a bucket or tray.

After Draining Pump You Must...

Step 5:

- Remove inlet hose either at pump or at separator.
- Pour 2 ounces (1/4 cup) of conditioning fluid (002-1910-02) into pump and let soak. or WD-40 if unavailable
- Try to work pulley loose as fluid migrates through pump.
- If pump will not free up order Timer/Conditioning Fluid Kit (002-1910-01) and Socket kit (002-1911-00)
- If pumps rotates freely restore power and start vacuum. Order Timer/Conditioning Fluid Kit (002-1910-01) if needed.



Models:
Serial Numbers:

All

Pump

B-51

Testing & Repair

Pump

Change Gear Lube

The PowerVac® gear lube should be changed every 10 years. It will take approximately 2/3 of a quart of Midmark PN 064-0028 which can be ordered in a quart or a liter.

Refer to:	Page
Pump Location and Function	B-50
Pump - Check	B-51
Front Cover	C-2

Step 1: Run PowerVac for 5-10 minutes.
Disconnect main power supply to the PowerVac.

Step 2: Remove front cover.
Note: Refer to Section C Front Cover

Step 3: Remove venting valve plug.


Step 4: Siphon gear lube out from venting valve hole.

Note: If you do not have a siphon hose, you may access the drain plug located below the site gauge. Place a oil absorbant mat under drain hole and funnel the gear lube out the side access hole in housing into a drain tray.

Step 5: Fill in new gear lube until the level is slightly above the middle of the site gauge. Verify seal ring on vent valve is undamaged. Replace vent valve plug and or drain plug. Clean any gear lube that leaked on inside or outside housing.

Note: Dispose of gear lube in compliance with applicable regulations.

Step 6: Replace front cover.
Connect main power supply.
Run pump for 5 minutes and recheck the gear lube on the site gauge.




Liquid Evacuation Pump (Accessory)

Function

The PowerVac® Liquid Evacuation Pump Accessory provides additional security for an extremely busy practice. Easily installed as OEM or as a later accessory, the Liquid Evacuation Pump ensures that the PowerVac® operates without interruption by automatically draining the separation tank periodically throughout the day.

Earlier Versions had Three Reed Switch Floats. The Middle Float was for the Liquid Evac Pump Option. If You Have a Liquid Evac Pump Connected to the PowerVac you Must Replace Float With a Three Reed Switch Float Assembly. If There is No Evac Pump Connected to the PowerVac, You can Replace the Float With a Two Reed Switch Float Assembly.



Earlier Version Shown

Refer to: [Page](#)
Evacuation Pump TestsB-53 thru B-57

Models:
Serial Numbers:

All

Liquid Evacuation Pump

B-53

Testing & Repair


Liquid Evacuation Pump (Accessory)

Testing (Power On, Float Switches Open, No LED's On)

Note: All Electrical leads are not shown for the purpose of clarity.

Step 4: 24 VAC should be present at J3 plug connector 1 (yellow wire) and 2 (blue wire) from Transformer.

Note: If 24 VAC is not present replace Transformer.



Refer to:

Page

Evacuation Pump TestsB-53 thru B-57



Caution

When testing components with power on use care to prevent electrical shock.

Step 1: With power on, 115 VAC is present at J6 & J7.

Note: If 115 VAC is not present check main supply power.

Step 2: 115 VAC should be present at plug connector 4 (Blk wire) and 3 (white wire) to Transformer.

Note: If 115 VAC is not present check fuse F1 and F3 and replace if necessary. If F1 & F3 fuses are good replace PC Board.

Step 3: 115 VAC should be present at plug connector 1 (Blk wire) and 2 (white wire) to Power On Light. Light should be on.

Note: If 115 VAC is not present check fuse F1 and F3 and replace if necessary. If 115 VAC is present but light is not on, replace light. If F1 & F3 fuses and light are good replace PC Board.

AA165103i

Liquid Evacuation Pump (Accessory)

Testing (Power On, Bottom & Middle Float Switches Closed, K4 Evac. Pump Relay coil energized)

Note: All Electrical leads are not shown for the purpose of clarity.




Caution

When testing components with power on use care to prevent electrical shock.

Refer to:

Page

Evacuation Pump TestsB-53 thru B-57



Note:

- LED's D3 & D4 will cycle On & Off as the Bottom & Middle Float Controls level of the fluid.
- When D4 is On, the contacts in the Evac. Relay (K4) close and power will be present at J8 & J9 to run the Evac. Pump.

Step 1: When D3 & D4 LED's are On 115 VAC should be present at J8 & J9.

Note: If 115 VAC is not present check Fuse F2. If F2 Fuse is good replace PC Board.

AA165101i

Models:
Serial Numbers:

All

Liquid Evacuation Pump

B-55

Testing & Repair

Liquid Evacuation Pump (Accessory)

Testing (Power on, All [D1, D3, D4] LED's on.
Bottom, Middle, and Top float switches closed.
K4 Evac. Pump Relay coil energized.)


Note: All Electrical leads are not shown for the purpose of clarity.

Refer to: [Page](#)
Evacuation Pump TestsB-53 thru B-57



Caution
When testing components with power on use care to prevent electrical shock.

- Note:**
- When all three LED's (D1, D3, D4) are on, it indicates the Separator Tank is full of liquid.
 - D4 indicates the Evacuation Pump Relay coil (K4) is energized, closing its contacts and supplying 115 VAC to terminals J8 & J9 to the Evac. Pump.
 - The Vacuum Pump shuts off when the contacts (K1) in the Top Float (D1) are closed.



Step 2: 115 VAC should be present at J8 & J9.

Note: If 115 VAC is *not* present check Fuse F2.
If F2 Fuse is good replace PC Board.
If 115 VAC is present check Evacuation Pump.

AA1651001

Liquid Evacuation Pump

Models: All
Serial Numbers:

Liquid Evacuation Pump (Accessory)

Testing Liquid Evacuation Pump Assembly


Note: The motor has a thermal protection that will open, removing power to the motor should it overheat. Ambient temperature around the pump should not exceed 104°F (40°C).

Refer to: [Page](#)
Evacuation Pump TestsB-53 thru B-57



Caution


When testing components with power on use care to prevent electrical shock.



Note: A full Separator Tank may be due to an obstruction in the outlet side of the system. Assure nothing is obstructing the flow of the discharge from the tank and Evac. Pump during operation.

Step 1: If pump motor is running but not pumping fluid.

Note: Turn power off to Evac. Pump. Check for restrictions / obstruction in the lines connected to the pump and remove obstacles. Remove cover plate (four screws) and check impeller for obstructions or wear. Replace if necessary.



Step 2: If pump motor is *not* running but has 115 VAC supplied to it (PC Board, J8 & J9) check thermal protector.

Note: Turn power Off and wait 15 minutes to allow motor to cool and thermal protector to reset. Disconnect Black & White motor leads from terminals J8 & J9 on the Evac. Pump PC Board. Set VOM to Ohms Ω . Place meter probes on the White and Black motor leads and check continuity.

Note: Refer to Section E for the Impeller / Gasket Kit.

AA165200i

Meter Reading

Status

Required Action

OL		Winding or Thermal Protector (TP) Stays Open. Replace Motor Pump
Continuity checks OK (20 to 30 ohms, cold reading)		Thermal protector is closed. Winding is within ohms range. Motor is ok.

Models: All
Serial Numbers:

Liquid Evacuation Pump

B-57

Testing & Repair

Separator Tank

Rinsing Separator Tank Assembly

Step 2: Remove pressure gauge from separator lid and temporarily replace with garden hose adapter.


Note: Garden hose adapter was supplied as a loose part when this unit was purchased.

Step 4: Run water through garden hose for approximately five (5) minutes.

Step 3: Attach garden hose (not shown) to garden hose adapter.

Step 5: Turn water off, disconnect hose, remove garden hose adapter and replace with pressure gauge.

Step 1: Turn On / Off switch to "Off" position.




Refer to: Page
Float Assembly CheckB-15 thru B-17

Separator Tank

Models: All
Serial Numbers:

Section C

Access Procedures



<u>Removing & Installing:</u>	<u>Page</u>
Front Cover	C-2
Top Cover	C-3
Electrical Cover	C-4
Back Cover (Previous Tank)	C-5
Back Cover with Large Tank	C-6

Access Procedures

Front Cover

Removal / Installation



Caution

Power must be disconnected when removing front cover. The On/Off switch controls only the secondary circuit power. The main power source must be turned off to remove all power in the control box.


Step 1: Unfasten front cover by turning each fastener 1/4 turn, counter clockwise.

Removal

Step 2: Lift front cover straight up to free plastic cones from holes in side panels.

Installation

Step 3: Align plastic cones to holes in side panels.




Installation

Step 4: Turn fasteners 1/4 turn clockwise to secure front cover.

Top Cover


Removal / Installation

 **Caution**
The On/Off switch controls only the secondary circuit power.
The main power source must be turned off to remove all power in the control box.

Removing & Installing: Page
Front Cover C-2

Removal
Step 1: Disconnect power.

Installation
Step 10: Connect power.



Removal
Step 5: Unbolt and remove top cover.


Installation
Step 6: Install top cover.



Removal
Step 2: Unplug float cord.

Installation
Step 9: Plug in float cord .

Float Cord



Removal
Step 3: Unbolt and remove separator from vacuum base unit if applicable.

Installation
Step 8: Install separator on top of vacuum base unit if applicable.

Removal
Step 4: Remove front cover.
Refer to: Section C - Front Cover

Installation
Step 7: Install front cover.

Models: | **All**
Serial Numbers: |

Top Cover

Access Procedures

Electrical Cover

Removal / Installation

Removal

Step 1: Disconnect power.



Installation

Step 6: Connect power.



Caution

The On/Off switch controls only the secondary circuit power. The main power source must be turned off to remove all power in the control box.



Caution

When testing components with power on use care to prevent electrical shock.

Removal

Step 2: Remove two screws from electrical panel.

Installation

Step 5: Install two screws.

Removal

Step 3: Remove electrical panel.

Installation

Step 4: Install electrical panel.


Back Cover

Removal / Installation

Removal
Step 2: Lift back cover straight up to free plastic cones from holes in side panels.


Installation
Step 5: Align plastic cones to holes in side panels.

Note
If there are hex head mounting bolts in rear cover, it has been installed using a retrofit kit. Unscrew all four bolts to remove rear cover.



Removal
Step 3: Unplug both fans.

Installation
Step 4: Plug in both fans.

Caution
 Power must be disconnected when removing back cover. The On/Off switch controls only the secondary circuit power. The main power source must be turned off to remove all power in the control box.

Step 1: Disconnect power supply. Unfasten back cover by turning each fastener 1/4 turn, counter clockwise.

Installation
Step 6: Turn fasteners 1/4 turn clockwise to secure back cover.


Models:	P3	P5	P7	All
Serial Numbers:	0802P3P0612 to Present	0801P5P0241 to Present	0712P7P0105 to Present	V785000 thru Present

Back Cover

Access Procedures

Removal

Step 1: Loosen front two bolts.
Remove rear bolts.



Removal

Step 2: Remove rear bolt.

Removal

Step 3: Tilt tank forward and pull back cover up and off.


Step 4: Reverse steps 1 thru 3 to install.

Section D

Wiring Diagrams

<u>Model</u>	<u>Page</u>
All	
Electrical Box	D-2*
Electrical System.....	D-3*
Accessory	
Liquid Evacuation Pump	D-4


* Indicates multiple pages due to model / serial number break(s)



Wiring Diagrams

Refer To: [Page](#)
Electrical Parts/Hardware E-11


Wire Harness	From:	To:	Part Number
A	Power Supply	Electrical Box	015-1896-00
B	Float Plug	Electrical Box	029-3792-00
C	Hour Meter Cable	Electrical Box	015-2028-00
D	Fuse	Contactor	015-2032-00 Jumper Wire
E	Electrical Box	Motor	015-2027-00
F	Fan	Contactor	015-2052-00
G	Low Voltage Connection	Contactor	015-2033-00
H	Low Voltage Connection	Terminal Block	015-2024-00
I	Low Voltage Connection	Relay	015-2026-00
J	Terminal Block	Relay	015-2031-00 Jumper Wire
K	Contactor	Relay	015-2030-00 Jumper Wire



Wiring Diagrams

Refer To: [Page](#)
Electrical Parts/Hardware E-11


Wire Harness	From:	To:	Part Number
A	Power Supply	Electrical Box	015-1896-00
B	Float Plug	Electrical Box	029-3792-00
C	Hour Meter Cable	Electrical Box	015-2028-00
D	Fuse	Contactora	015-2032-00 Jumper Wire
E	Electrical Box	Motor	015-2027-00
F	Fan	Contactora	10571800
G	Low Voltage Connection	Contactora	015-2033-00
H	Low Voltage Connection	Terminal Block	015-2024-00
I	Low Voltage Connection	Relay	015-2026-00
J	Terminal Block	Relay	015-2031-00 Jumper Wire
K	Contactora	Relay	015-2030-00 Jumper Wire



Models:	P3	P5	P7	All
Serial Numbers:	0802P3P0612 to Present	0801P5P0241 to Present	0712P7P0105 to Present	V785000 thru Present


Wiring Diagrams

Wiring Diagrams



62980400 Rev A


Wiring Diagrams



Models:	P3	P5	P7	All
Serial Numbers:	0802P3P0612 to V1648734	0801P5P0241 to V1648734	0712P7P0105 to V1648734	V785000 thru V1648734

Wiring Diagrams

Wiring Diagrams



D-3.2

Wiring Diagrams

Models:
Serial Numbers:

P3
V1648735 to Present

P5
V1648735 to Present

P7
V1648735 to Present

All
V1648735 thru Present


Wiring Diagrams

Refer To:

Page

Liquid Evacuation Pump Repair Kit E-14


Earlier Versions had Three Reed Switch Floats. The Middle Float was for the Liquid Evac Pump Option. If You Have a Liquid Evac Pump Connected to the PowerVac you Must Replace Float With a Three Reed Switch Float Assembly. If There is No Evac Pump Connected to the PowerVac, You can Replace the Float With a Two Reed Switch Float Assembly.



Section E

Exploded Views & Parts Lists

Model	Page
P3, P5, P7 (Single Units)	E-2
P6, P10, P14 (Twin Units)	E-3
Accessory (All Models)	
Liquid Evacuation Pump	E-4




PowerVac®

P3

P5

P7



* Indicates multiple pages due to model / serial number break(s)

PowerVac®

P6


P10

P14


Vacuum Base Unit E-9*
Loose parts E-10*
Shipping Bolt Assy E-17

Front Panel Controls .. E-12*

Labels E-16*



Twin Tee Assembly E-7



Separator Assembly ... E-5*
Loose parts E-6*

Fan Assembly E-13*


Drain Assembly E-8*

Electrical Box E-12*


AA161100i

* Indicates multiple pages due to model / serial number break(s)

Liquid Evacuation Pump (Accessory)



Earlier Version Shown



Refer To:	Page
Drain Assembly	E-8
Vacuum Relief Valve . Adjustment	B-9

Earlier Versions had Three Reed Switch Floats. The Middle Float was for the Liquid Evac Pump Option. If You Have a Liquid Evac Pump Connected to the PowerVac you Must Replace Float with a Three Reed Switch Float Assembly. If There is No Evac Pump Connected to the PowerVac, You can Replace the Float with a Two Reed Switch Float Assembly. See Next Page for Two Float Assembly PN

Note
 Single models require one separator assembly.
 Twin models require two separator assemblies.
 NLA = No Longer Available

Item	Description	Qty.
1	Vacuum Relief Valve (Twin Unit location is on Tee Assembly)	
	a) Valve with Filter	1
	b) Filter Only	1
2	Gauge Vac 2" x 1/4" NPT	1
3	NLA - (Replace with 029-5144-00)	Ref
4	Wash Down Fitting	1
5	Gasket	1
6	Refer to: Drain Assembly	Ref
7	NLA -1/4" 20 x 1/2" Pan Head Phillips 'TT' .	6
8	NLA -Legs	3
9	NLA - (Replace with 029-5144-00)	Ref
10	Float Assembly	1
11	Bulkhead Assembly w/45	1
12	Bracket	1
13	Pipe Nipple 1-1/2" NPT	1
14	Elbow 90, 1-1/2" NPT	1
15	Bulkhead Fitting 1-1/2"	1
16	Tee Fitting	1
17	Cap (Twin Units Only)	1

AA157600i

Always Specify Model & Serial Number


Models:	P3	P5	P7
Serial Numbers:	V245092 to V975824 0611P3P0000 thru Present	V245092 to V975824 0611P5P0000 thru Present	V245092 to V975824 0611P7P0000 thru Present

Separator

Refer To:	Page
Drain Assembly	E-8
Vacuum Relief Valve Adjustment	B-9

Earlier Versions had Three Reed Switch Floats. The Middle Float was for the Liquid Evac Pump Option. If You Have a Liquid Evac Pump Connected to the PowerVac you Must Replace Float with a Three Reed Switch Float Assembly. If There is No Evac Pump Connected to the PowerVac, You can Replace the Float with a Two Reed Switch Float Assembly. See Next Previous Page for Three Float Assembly PN

Note
Single models require one separator assembly.
Twin models require two separator assemblies.



Item	Description	Qty.
1	Separator Assembly (includes items 2-17)	1
2	Gasket	1
3	Tank	1
4	Legs	3
5	1/4" 20 x 1/2" 'TT'	6
6	Refer to: Drain Assembly	Ref
7	Float Assembly	1
8	Bulkhead Assembly w/45	1
9	Wash Down Fitting	1
10	Pipe Nipple 1-1/2" NPT	1
11	Bracket	1
12	Separator Lid	1
13	Bulkhead Fitting 1-1/2"	1
14	Gauge Vac 2" x 1/4" NPT	1
15	Elbow 90, 1-1/2" NPT	1
16	Tee Fitting	1
17	Cap (Twin Units Only)	1
18	Vacuum Relief Valve	1
<i>(Twin Unit location is on Tee Assembly)</i>		
a)	Valve Assembly with Filter	1
b)	Filter Only	1

Always Specify Model & Serial Number


Separator	Models: Serial Numbers:	P3 V975825 to V1465490	P5 V975825 to V1465490	P7 V975825 to V1465490
-----------	----------------------------	---------------------------	---------------------------	---------------------------

AA2259

Refer To:	Page
Drain Assembly	E-8
Vacuum Relief Valve Adjustment	B-9

Earlier Versions had Three Reed Switch Floats. The Middle Float was for the Liquid Evac Pump Option. If You Have a Liquid Evac Pump Connected to the PowerVac you Must Replace Float With a Three Reed Switch Float Assembly. If There is No Evac Pump Connected to the PowerVac, You can Replace the Float With a Two Reed Switch Float Assembly. See Next Previous Page for Three Float Assembly PN

Note
Single models require one separator assembly.
Twin models require two separator assemblies.




Item	Description	Qty.
1	Separator Assembly (includes items 2-17)	1
2	Gasket	1
3	Tank	1
4	Legs	3
5	1/4" 20 x 1/2" 'TT'	6
6	Refer to: Drain Assembly	Ref
7	Float Assembly	1
8	Bulkhead Assembly w/45	1
9	Wash Down Fitting	1
10	Pipe Nipple 1-1/2" NPT	1
11	Bracket	1
12	Separator Lid	1
13	Bulkhead Fitting 1-1/2"	1
14	Gauge Vac 2" x 1/4" NPT	1
15	Elbow 90, 1-1/2" NPT	1
16	Tee Fitting	1
17	Cap (Twin Units Only)	1
18	Vacuum Relief Valve	1
<i>(Twin Unit location is on Tee Assembly)</i>		
a)	Valve Assembly with Filter	1
b)	Filter Only	1

Always Specify Model & Serial Number

Beginning Serial Number Label on Separator Tanks

Models:	P3	P5	P7
Serial Numbers:	V1465491 to present	V1465491 to present	V1465491 to present

Separator



Item	Description	Qty.
<i>(includes items 1 thru 8)</i>		
1	Bushing 2" MPT x 1 1/2" FPT (Exhaust)	1
2	Adapter 1 1/2" (PVC)	1
Hose Assembly <i>(includes items 3 & 4)</i>		
3	Swivel Connector	2
4	Intake Hose 1 1/2" x 6'	1
5	Drain Hose 1" x 6'	1
6	Garden Hose Adapter	1
7	Pipe Nipple (Threaded, Plastic)	1

Always Specify Model & Serial Number

AA161300i

This page is intentionally blank

Always Specify Model & Serial Number

Models: |
Serial Numbers: |



E-6.1

**Top Section are
 Extra Fittings for
 Intake and VRV
 Hose Connections
 to Existing Pipes
 from Separator**


1 002-1441-01

Note


This loose parts kit is only for separator components only.

Item	Description	Qty.
1	Separator Loose Parts (includes items 2 thru 12)	
2	• Nipple, PVC, 1 1/4"	1
3	• Busing, PVC, 1 1/2" NPM x 1 1/4" NPT ...	1
4	• Clamp, Worm Gear, 2"	1
5	• Bushing 2" NPT x 1.5" FPT, (PVC)	1
6	• Coupling Reducer SOC 2" x 1"	1
7	• Adapter, 1 1/2" NPT x Socket, (PVC)	1
8	• Coupler 1 1/2" SOC 2" x 1" (PVC)	1
9	• Adapter, 1 1/2" NPT x Socket, (PVC)	1
10	• Garden Hose Adapter	1
11	Drain Hose Assembly, 1 1/2" I.D.	1
12	Intake Hose Assembly, 1 1/2" I.D.	1

Always Specify Model & Serial Number



AA161302i




Item	Description	Qty.
1	Tee Assembly (Single to Twin Dry Vac Kit) (includes items 1 thru 18)	
2	Adapter 2" MIPT x SOC	1
3	Reducer Bushing 2" x 1 1/2"	1
4	Tee 1 1/2" FPT Brass	1
5	Cap 1"	2
6	Wall Anchor 3/16" x 1 1/4"	5
7	Washer Fender 1/4 Bolt x 1" O.D.	5
8	Screw #8 x 1 1/2" Pan	5
9	Cross 2" NPT	1
10	Check Valve	2
11	Pipe Nipple 1 1/2" NPT	4
12	Union 2" NPT x 2" NPT	1
13	2" Hose Assembly	1
14	Reducer Busting 2" x 1"	1
15	Pipe Nipple 1" NPT	1
16	Y Female Fitting 1 1/2"	1
17	Barb Fitting (1 1/2" Hose)	3
18	Bracket	1

Always Specify Model & Serial Number

AA167200i

Models:	P6	P10	P14
Serial Numbers:	All	All	All

Tee Assembly




Item	Description	Qty.
029-3839-00 Drain Assembly (includes items 1 thru 10)		
1	Barb Connector 1/2 MPT (NLA)	1
2	Bushing 1 x 1/2 NPT (NLA)	1
3	Ball Valve (NLA)	1
4	Nipple 1"	1
5	Nipple 1 1/2"	2
6	Tee 1 1/2" FPT	1
7	Check Valve 1 1/2"	1
8	Elbow, ST, 1 1/2" NPT (NLA)	1
9	Reducer 1 1/2 NPT x 1" NPT	1
10	Drain Hose	1
11	Loctite 542 Sealant (10566800 - Not Shown)	

AA161200i

Always Specify Model & Serial Number

Drain Assembly

Models: Serial Numbers:	P3 V245092 to V317654	P5 V245092 to V317641	P7 V245092 to V317634
----------------------------	--------------------------	--------------------------	--------------------------




AA161201i

Item	Description	Qty.
	029-3839-00 Drain Assembly (includes items 1 thru 10)	
1	Barb Connector 1/2 MPT (NLA)	1
2	Bushing 1 x 1/2 NPT(NLA)	1
3	Ball Valve (NLA)	1
4	Nipple 1"	1
5	Nipple 1 1/2"	2
6	Tee 1 1/2" FPT	1
7	Check Valve 1 1/2"	1
8	Elbow, ST, 1 1/2" NPT(NLA)	1
9	Reducer 1 1/2 NPT x 1" NPT	1
10	Drain Hose	1
11	Loctite 542 Sealant (10566800 - Not Shown)	

Always Specify Model & Serial Number

Models:	P3	P5	P7
Serial Numbers:	0611P3P0000 to 0804P3P0751	0611P5P0000 to 0804P5P0310	0611P7P0000 to x0804P7P0134

Drain Assembly



Item	Description	Qty.
	029-3839-00 Drain Assembly (includes items 1 thru 10)	
1	Drain Hose	1
2	Check Valve 1 1/2"	1
3	Nipple 1 1/2"	1
4	Tee 1 1/2" FPT	1


Always Specify Model & Serial Number

AA161202i

E-8.2

Drain Assembly

Models:	P3	P5	P7	All
Serial Numbers:	0804P3P00752 thru V1651590	0804P5P0311 thru V1651590	0804P7P0135 thru V1651590	V785000 thru V1651590



Item	Description	Qty.
	029-3839-00 Drain Assembly (includes items 1 thru 10)	
1	Drain Hose	1
2	Check Valve 1 1/2"	1
3	Nipple 1 1/2"	1
4	Tee 1 1/2" FPT	1

Always Specify Model & Serial Number

Models:	P3	P5	P7	All
Serial Numbers:	V1651591 thru Present	V1651591 thru Present	V1651591 thru Present	V1651591 thru Present

Drain Assembly


This page is intentionally blank

Always Specify Model & Serial Number

E-8.4



Models: |
Serial Numbers: |




Note
 Old style motor shown, new motor has internal automatic thermal overload.

Item	Description	Qty.
1	1/4" -20 Hex Head Bolt	3
2	1/4" Lock Washer	3
3	Top Cover Assembly	1
4	Motor	1
5	Motor Mount Assembly	1
6	1" ID Hose Assembly	1
7	1" Fitting x 1" NPT	2
8	Exhaust Check Valve	1
9	Sight Glass (Torque to 132 in/lbs)	1
10	Leveling Feet-Slide	4
11	Right Panel	1
12	5/16"-18 x 3/4" Hex Head Bolt	16
13	3/8"-16 x 1/2" Hex Head Bolt	12
14	M8 x 10MM Hex Head Bolt	3
15	Casters	4
16	Fastener 1/4 turn	2
17	Tapered pin	2
18	Hex washer head screw #10 x 1/2"	2
19	Front Cover Assembly	1
20	Pump (includes item 7, 9, & bottom plate)	1
21	Left Panel Assembly	1
22	a) Belt Models - P3, P5, P6, P10	1
	b) Belt Models - P7, P14	1
23	Capacitors	
	a) Run (60uF +/-6%, 370VAC, 50/60Hz)	1
	b) Start (295-355uF, 125VAC, 50/60Hz)	1
*Not Shown		
24	*Gear Lube	(064-0028-01)
25	*Belt Tension Checker Tool	(016-1064-00)
26	*Touch Up Paint (Brush-On)	(067-0053-02-366)
27	*Touch Up-Paint (Aerosol)	(067-0053-01-366)

AA167402-2i

Always Specify Model & Serial Number

Models:	P3	P7	P5
Serial Numbers:	V245092 to V317654	V245092 to V317634	V245092 to V317641



Note
 Old style motor shown, new motor has internal automatic thermal overload.

Item	Description	Qty.
1	1/4" -20 Hex Head Bolt	3
2	1/4" Lock Washer	3
3	Top Cover Assembly	1
4	Motor	1
5	Motor Mount Assembly	1
6	1" ID Hose Assembly	1
7	1" Fitting x 1" NPT	2
8	Exhaust Check Valve	1
9	Sight Glass (Torque to 132 in/lbs)	1
10	Leveling Feet-Slide	4
11	Right Panel	1
12	5/16"-18 x 3/4" Hex Head Bolt	16
13	3/8"-16 x 1/2" Hex Head Bolt	12
14	M8 x 10MM Hex Head Bolt	3
15	Casters	4
16	Fastener 1/4 turn	2
17	Tapered pin	2
18	Hex washer head screw #10 x 1/2"	2
19	Front Cover Assembly	1
20	Pump (includes item 7, 9, & bottom plate) ..	1
21	Left Panel Assembly	1
22	a) Belt Models - P3, P5, P6, P10	1
	b) Belt Models - P7, P14	1
23	Capacitors	
	a) Run (60uF +/-6%, 370VAC, 50/60Hz)	1
	b) Start (295-355uF, 125VAC, 50/60Hz) ...	1
*Not Shown		
24	*Gear Lube	(064-0028-01)
25	*Belt Tension Checker Tool	(016-1064-00)
26	*Touch Up Paint (Brush-On 067-0053-02-366)	
27	*Touch Up-Paint (Aerosol 067-0053-01-366)	
Always Specify Model & Serial Number		


E-9.1

Vacuum Base Unit

Models:	P3	P5	P7
Serial Numbers:	0611P3P0000 to 0801P3P0611	0611P5P0000 to 0801P5P0240	0611P7P0000 to 0712P7P0104

Note

Old style motor shown,
new motor has internal
automatic thermal
overload.




Item	Description	Qty.
1	1/4" -20 Hex Head Bolt	3
2	1/4" Lock Washer	3
3	Top Cover Assembly	1
4	Motor	1
5	a) P3 & P5 Motor Mount (Retro Kit)	1
	b) P7 Motor Mount (Retro Kit)	1
	c) Idler Pulley Assembly Only	1
6	1" ID Hose Assembly	1
7	1" Fitting x 1" NPT	2
8	Exhaust Check Valve (Twin Units Only)	1
9	Sight Glass (Torque to 132 in/lbs)	1
10	Leveling Feet-Slide	4
11	Right Panel	1
12	5/16"-18 x 3/4" Hex Head Bolt	16
13	3/8"-16 x 1/2" Hex Head Bolt	12
14	M8 x 10MM Hex Head Bolt	3
15	Casters	4
16	Fastener 1/4 turn	2
17	Tapered pin	2
18	Hex washer head screw #10 x 1/2"	2
19	Front Cover Assembly	1
20	Pump (includes item 7, 9, & bottom plate) ..	1
21	Left Panel Assembly	1
22	a) Belt Models - P3, P5, P6, P10	1
	b) Belt Models - P7, P14	1
23	Capacitors	
	a) Run (60uF +/-6%, 370VAC, 50/60Hz)	1
	b) Start (295-355uF, 125VAC, 50/60Hz) ...	1
24	Rear Cover	1
25	*Gear Lube	(064-0028-01)
26	*Touch Up Paint (Brush-On 067-0053-02-366)	
27	*Touch Up-Paint (Aerosol 067-0053-01-366)	

Always Specify Model & Serial Number

Models:	P3	P5	P7
Serial Numbers:	0802P3P0612 to 0905P3P1203	0801P5P0241 to 0902P5P0526	0712P7P0105 to 0902P7P0232

Vacuum Base Unit





*Not Shown

Item	Description	Qty.
1	1/4" -20 Hex Head Bolt	3
2	1/4" Lock Washer	3
3	Top Cover Assembly	1
4	Motor	1
5	a) P3 & P5 Motor Mount (Retro Kit)	1
	b) P7 Motor Mount (Retro Kit)	1
	c) Idler Pulley Assembly Only	1
6	1" ID Hose Assembly	1
7	1" Fitting x 1" NPT	2
8	Exhaust Check Valve (Twin Units Only)	1
9	Sight Glass (Torque to 132 in/lbs)	1
10	Leveling Feet-Slide	4
11	Right Panel	1
12	5/16"-18 x 3/4" Hex Head Bolt	16
13	3/8"-16 x 1/2" Hex Head Bolt	12
14	M8 x 10MM Hex Head Bolt	3
15	Casters	4
16	Fastener 1/4 turn	2
17	Tapered pin	2
18	Hex washer head screw #10 x 1/2"	2
19	Front Cover Assembly	1
20	Pump (includes item 7, 9, & bottom plate) ..	1
21	Left Panel Assembly	1
22	a) Belt Models - P3, P5, P6, P10	1
	b) Belt Models - P7, P14	1
23	Capacitors	
	a) Run (60uF +/-6%, 370VAC, 50/60Hz)	1
	b) Start (295-355uF, 125VAC, 50/60Hz) ...	1
24	Rear Cover	1
25	*Gear Lub	(064-0028-01)
26	*Touch Up Paint (Brush-On 067-0053-02-366)	
27	*Touch Up-Paint (Aerosol 067-0053-01-366)	

Always Specify Model & Serial Number

Vacuum Base Unit

Models:	P3	P5	P7	All
Serial Numbers:	0905P3P1204 to Present	0902P5P0527 to Present	0902P7P0233 to Present	V785000 thru Present




Item	Description	Qty.
1	1" Fitting x 1" MPT	1
2	Bushing 1" FPT x 2" MPT (NLA)	1
3	Bushing 1" FPT x 1 1/2" MPT (NLA)	1
4	Hose 1" x 8' Low Pressure EPDM (Exhaust)	1
5	Wrench, Twin Open-End 1/2"	1
6	#8 x 1 1/2" Fl Head PHL Screw (NLA)	8
7	Skid Removal Brackets (NLA)	2

Always Specify Model & Serial Number

AA168101i


Models:	P3	P5	P7	All Models
Serial Numbers:	0611P3P0000 to Present	0611P5P0000 to Present	0611P7P0000 to Present	V245092 thru V1219385

Vacuum Loose Parts



Item	Description	Qty.
1	Loose Parts (includes items 1 - 13)	
2	• 1" Fitting x 1" MPT	1
3	• Bushing 1" FPT x 2" MPT (NLA)	3
4	• Bushing 1" FPT x 1 1/2" MPT (NLA)	1
5	• Hose	1
6	• Wrench, Twin Open-End 1/2"	1
7	• Poly Flo Tubing (NLA)	12 ft
8	• Barbed Fitting, Male (NLA)	1
9	• Reducer, 1/2" NPT-1/8" NPT (NLA)	1
10	• Elbow, 1.5", PVC, Sch 40	2
11	• Bushing, 1.5" x 1", PVC, Sch 40	1
12	• Tee, 1.5", PVC, Sch 40	1
13	• Bushing, 1.5" x .5", PVC, Sch 40	1

Always Specify Model & Serial Number



Note

Single models require one vacuum assembly.
Twin models require two vacuum assemblies.


Item	Description	Qty.
1	Loose Parts (includes items 1 - 13)	
2	• Elbow, 1.5", PVC, Sch 40	2
3	• Bushing, 1.5" x 1", PVC, Sch 40	1
4	• 1" Fitting x 1" MPT	1
5	• Tee, 1.5", PVC, Sch 40	1
6	• Bushing, 1.5" x .5", PVC, Sch 40	1
7	• Wrench, Twin Open-End 1/2"	1
8	• Hose, Exhaust	1
9	• Connector, Wire (Blue)	4
10	• Assy, Timer PCB Enclosure	1
11	• 3/8" Drain Tube Kit (Includes 12 & 13) .	12 ft
12	• Barbed Fitting, Male	1
13	• Reducer, 1/2" NPT-1/8" NPT	1

Always Specify Model & Serial Number

Models: All
Serial Numbers: V1648735 to Present

Vacuum Loose Parts **E-10.2**

This page is intentionally blank



Note
 Single models require one vacuum assembly.
 Twin models require two vacuum assemblies.

Refer To:	Page
Relay .. Test	B-30
Fuse .. Test	B-27
Transformer .. Test	B-33
Contactor .. Test	B-25


Item	Description	Qty.
1	Electrical Cover	1
2	#10 -24 x 3/8 Pan Head Screw	2
3	#8 x 3/8 Serrated Head Metal Screw	4
4	Relay DPDT, General Purpose	1
5	Screw (#8-32 x 5/8")	2
6	Terminal Block	1
7	Fuse 1/8A, 1/4 X 1-1/4, Type T SLO-BLO ..	1
8	Screw	1
9	Fuseblock, 1/4in X 1-1/4in FUSE	1
10	Nut Keps 10/32	5
11	Electrical Box	1
12	Screw (#8-32 x 5/16")	2
13	Transformer, 240V, 50/60 HZ	1
14	Din-3 Rail, 5.8"	1
15	Contactor	1
16	Door Limit Switch	1
17	Mounting Bracket (Limit Switch)	1
18	#10-24 x 5/8 Pan Head Type "TT"	1
19	Track, Mount, DPDT Relay Socket	1

Always Specify Model & Serial Number

Models:	P3	P5	P7
Serial Numbers:	V245092 to V317654	V245092 to V317641	V245092 to V317634

Electrical Box Assembly

E-11



Refer To:	Page
Relay .. Test	B-30
Fuse .. Test	B-27
Transformer .. Test	B-33
Contactor .. Test	B-25

Note
 Single models require one vacuum assembly.
 Twin models require two vacuum assemblies.


Item	Description	Qty.
1	Electrical Cover	1
2	#10 -24 x 3/8 Pan Head Screw	2
3	#8 x 3/8 Serrated Head Metal Screw	4
4	Relay DPDT, General Purpose	1
5	Screw (#8-32 x 5/8")	2
6	Terminal Block	1
7	Fuse 1/8A, 1/4 X 1-1/4, Type T SLO-BLO ..	1
8	Screw	1
9	Fuseblock, 1/4in X 1-1/4in FUSE	1
10	Nut Keps 10/32	5
11	Electrical Box	1
12	Screw (#8-32 x 5/16")	2
13	Transformer, 240V, 50/60 HZ	1
14	Din-3 Rail, 5.8"	1
15	Contactor	1
16	Door Limit Switch	1
17	Mounting Bracket (Limit Switch)	1
18	#10-24 x 5/8 Pan Head Type "TT"	1
19	Track, Mount, DPDT Relay Socket	1

Always Specify Model & Serial Number

Electrical Box Assembly

Models:	P3	P5	P7	All
Serial Numbers:	0611P3P000 to Present	0611P5P000 to Present	0611P7P000 to Present	V785000 thru Present

Refer To:	Page
On/Off Switch ... Test	B-20
Door Limit Switch ... Test	B-20



Note
 Single models require one vacuum assembly.
 Twin models require two vacuum assemblies.


AA167500i

Item	Description	Qty.
1	Strain Relief Bushing	1
2	Nut Keps 6/32 (NLA)	2
3	Screw 6/32 x 1/2"	2
4	Hour Meter	1
5	On/Off Switch (Circuit Breaker)	1
6	Receptacle, Amp Mini CPC, 11/4 Reverse	1
7	Electrical Box Assembly	1
	Refer to: Electrical Box Assembly	REF
8	Door Limit Switch	1

Always Specify Model & Serial Number

Models:	P3	P5	P7
Serial Numbers:	V245092 to V317654	V245092 to V317641	V245092 to V317634

Front Panel Controls



Note
 Single models require one vacuum assembly.
 Twin models require two vacuum assemblies.


Item	Description	Qty.
1	Strain Relief Bushing	1
2	Nut Keps 6/32	2
3	Screw 6/32 x 1/2"	2
4	Hour Meter	1
5	On/Off Switch (Circuit Breaker)	1
6	Receptacle, Amp Mini CPC, 11/4 Reverse	1
7	Electrical Box Assembly	1
	Refer to: Electrical Box Assembly	REF
8	Door Limit Switch	1

Always Specify Model & Serial Number

AA167500i

Front Panel Controls

Models:	P3	P5	P7	All
Serial Numbers:	0611P3P0000 to Present	0611P5P0000 to Present	0611P7P0000 to Present	V785000 thru Present




Note
 Single models require one vacuum assembly.
 Twin models require two vacuum assemblies.

Item	Description	Qty.
1	Screw 8/32" x 1/2" Hex Head	4
2	Screw 1#10-24 x 1/4"	3
3	Bracket, Fan Mount Dry Vacuum	1
4	Fan, 230V	1
5	Fan Guard	1

Always Specify Model & Serial Number

Models:	P3	P5	P7
Serial Numbers:	V245092 to V317654	V245092 to V317641	V245092 to V317634

Fan Assembly



Note
 Single models require one vacuum assembly.
 Twin models require two vacuum assemblies.


Item	Description	Qty.
1	Screw 8/32" x 1/2" Hex Head	4
2	Screw 1#10-24 x 1/4"	3
3	Bracket, Fan Mount Dry Vacuum	1
4	Fan, 230V	1
5	Fan Guard	1

Always Specify Model & Serial Number

E-13.1

Fan Assembly

Models:	P3	P5	P7
Serial Numbers:	0611P3P0000 to 0801P3P0611	0611P5P0000 to 0801P5P0240	0611P7P0000 to 0712P7P0104




AA221700

Item	Description	Qty.
1	Screw 8/32" x 1/2" Hex Head	16
2	Fan, 230V	1
3	Fan Guard	1

Always Specify Model & Serial Number

Models:	P3	P5	P7
Serial Numbers:	0802P3P0612 to 0806P3P0828	0801P5P0241 to 0807P5P0372	0712P7P0105 to 0807P7P0160

Fan Assembly



AA221700


Item	Description	Qty.
1	Screw 8/32" x 1/2" Hex Head	16
2	Fan, 230V	1
3	Fan Guard	1

Always Specify Model & Serial Number

E-13.3

Fan Assembly

Models:	P3	P5	P7	All
Serial Numbers:	0806P3PO829 to Present	0807P5PO373 to Present	0807P7PO161 to Present	V785000 thru Present




Item	Description	Qty.
1	Accessory Control Box Assembly (NLA) 1 (Includes Items 2 - 10)	1
2	Transformer	1
3	#8 - 32 x 1/2" TYP Hex Screw	2
4	#8 Tooth Lock Washer	2
5	125 VAC Pilot Light	1
6	3 Amp Slow Blo Fuse	1
7	1/2 Amp Slow Blo Fuse	2
8	Socket (NLA)	1
9	Cord Assembly (NLA)	1
10	PC Board (NLA)	1
11	#8-32 x 3/8" Pan Head PHL Screw	4

Always Specify Model & Serial Number

AA168000i

Models: All
Serial Numbers: Production Date 3-13-2006 to 11-6-2006


**Electrical Accessory Box
 Liquid Evacuation Pump**



Item	Description	Qty.
1	Accessory Control Box Assembly (NLA)	1
	<i>(Includes Items 2 - 10)</i>	
2	Transformer	1
3	#8 - 32 x 1/2" TYP Hex Screw	2
4	#8 Tooth Lock Washer	2
5	125 VAC Pilot Light	1
6	3 Amp Slow Blo Fuse	1
7	1/2 Amp Slow Blo Fuse	2
8	Socket and Harness Assembly (NLA)	1
9	Cord Assembly (NLA)	1
10	PC Board (NLA)	1
11	#8-32 x 3/8" Pan Head PHL Screw	4

Always Specify Model & Serial Number

AA168000i




Item	Description	Qty.
1	Evacuation Pump (NLA)	1
2	1/2" Clear Hose 11" (by the foot)	1
3	ST 1/2 x 1/2" (NLA)	2
4	Reducer 3/4" NPT - 1/2" NPT	2
5	Spring Clamp	7
6	Check Valve	1
7	1/2" Clear Hose, 72" (by the foot)	2

Always Specify Model & Serial Number

AA167900i

Models: All
Serial Numbers: Production Date 3-13-2006 to 11-6-2006


Liquid Evacuation Pump



AA222000

Item	Description	Qty.
002-0938-00	Sep Auto Drain with Controls	
Items 1 thru 6		
002-0938-01-NLA	Sep Auto Drain without Controls	
Items 2 thru 6		
1	Control/Electrical Box (NLA)	1
2	Evacuation Pump Assembly (NLA)	1
3	3/8" Check Valve	2
4	Clamp (.5 Spring Steel)	2
5	Hose (1/2"ID x 72"L Wire Reinforced)(NLA)	2
6	Ball Valve (NLA)	1
Always Specify Model & Serial Number		


Models: All
Serial Numbers: Production Date 2-29-2008 to Present



AA167801i

Item	Description	Qty.
1	Input Voltage Label	1
2	Serial Number Label	1
3	C.U.S. Classification Label	1
4	IPOX Label	1
5	Patent Pending Label	1
6	Vacuum Exhaust Label	1
7	Earth (Ground) Label	1
8	Vacuum Schematic	1
9	Fuse Replacement Label	1
10	Caution Label	1
11	Midmark Logo	1
12	Caution Label	1
13	PowerVac Label	1
14	Hot Surface Label	1

Always Specify Model & Serial Number



AA167801i

Item	Description	Qty.
1	Input Voltage Label	1
2	No Longer Available - Classification Label ...	1
3	IPOX Label	1
4	Patent Pending Label	1
5	Vacuum Exhaust Label	1
6	Earth (Ground) Label	1
7	Vacuum Schematic	1
8	Serial Number Label	1
9	Fuse Replacement Label	1
10	Caution Label	1
11	Midmark Logo	1
12	Caution Label	1
13	PowerVac Label	1
14	Hot Surface Label	1

Always Specify Model & Serial Number

Models:	P3	P5	P7	All
Serial Numbers:	0611P3P0000 to Present	0611P5P0000 to Present	0611P7P0000 to Present	V785000 thru Present

Labels

ATTENTION: CUSTOMER SERVICE DEPARTMENT

IMPORTANT NOTES:

- 1) **Use this form for all non-warranty orders only.** Warranty orders must be telephoned in (1-800-643-6275).
- 2) FAX numbers to send order to:

1-877-725-6495
- 3) All emergency orders must be received @ Midmark by 1:00 pm EST.
- 4) All underlined headings should be filled in prior to submittal.

ADDITIONAL COMMENTS:

SERVICE PARTS FAX ORDERING FORM

(Do not tear out this page. Photo copy this page for use only.)



DATE: ___ / ___ / ___	TIME: _____	am pm
METHOD OF SHIPMENT: _____		
PRIORITY:	<input type="checkbox"/>	NON-EMERGENCY ORDER {to ship within 72 hours if part(s) are in stock.}
	<input type="checkbox"/>	EMERGENCY ORDER {to ship within 24 hours if part(s) are in stock.} [see note 3]

DEALER P.O. #: _____
ACCOUNT #: _____

MODEL #: _____	SERIAL #: _____	SALES ORDER # (if applicable) _____
----------------	-----------------	--

NAME: _____ ADDRESS: _____ CITY: _____ STATE: _____ ZIP: _____ CONTACT: _____ PHONE: _____ FAX #: _____	SHIP TO: _____ _____ _____ _____ _____
--	--

LINE #	PART NUMBER	QTY.	DESCRIPTION	COLOR (if applicable)

CREDIT CARD INFORMATION			
CARD TYPE _____	CARD # _____ - _____ - _____	EXP. DATE _____ / _____ / _____	NAME ON CARD _____ SIGNATURE _____

Midmark Corporation
60 Vista Drive
P.O. Box 286
Versailles, OH 45380-0286
937-526-3662
Fax 937-526-5542
www.midmark.com



Because we care.